



The Home Depot Pop Up Drain with Overflow Instructions

[Home](#) » [THE HOME DEPOT](#) » The Home Depot Pop Up Drain with Overflow Instructions 

THE HOME

Instruction Pull Down Bathroom Faucet Pop-up Drain with overflow Installation Guide

Contents

- [1 Pop Up Drain with Overflow](#)
- [2 WARMTIPS:](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)

Pop Up Drain with Overflow

NOTES:

Fits for sink WITH overflow hole.

Clean the sink hole, make sure to remove debris. Please avoid using plumber's putty.


The seal on top is leak-free.

Plumber's putty might cause damage.

Silicone and plumbing tape can be use for sealing requirement.




1. Unscrow components A&B



2. Slide the drain body C through the hole in the sink.



3. Screw components A & B back on as shown.



4. Connect the rear end of the drain to the Drain Pipe.



5. Push to activate.



1. Put the cover on the table.

2. insert all the hoses and the faucet into the sink hole.



3. Put the rubber gasket, steel washer and the nut in sequence upward.

4. Use a phillips screwdriver to tighten the screws.



5. Install the other side of the inlet hose to the angle valve.
6. Clasp the weight to the “weight Here” label.

WARMTIPS:

1. Flush the block and the water supply pipes thoroughly before installation.
2. Avoid sharp objects and acidic detergent on the surface of the faucet.
3. Clean the surface of the faucet regularly.

If you have any problem with this purchase, please contact with us any time.

We will try our best to solve your problem.

(Email: ” dlem@pobosales.com)

Customer Service Team

WARNING:

This is not a toy, To avoid danger , keep this plastic bag away from babies and children. Keep the extra accessories.

Documents / Resources

	<p>The Home Depot Pop Up Drain with Overflow [pdf] Instructions Pop Up Drain with Overflow, Drain with Overflow, with Overflow, Overflow</p>
---	--

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.