



[Home](#) » [THE HOME DEPOT](#) » **The Home Depot Wipe Surfaces with Mild Soap Solution and Soft Cloth User Manual** 

Contents [[hide](#)]

- [1 The Home Depot Wipe Surfaces with Mild Soap Solution and Soft Cloth](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)



The Home Depot Wipe Surfaces with Mild Soap Solution and Soft Cloth



Product Information

Specifications:

- **Weight Limits:** 500 lbs for benches, 200 lbs for tabletop
- **Cleaning:** Wipe with mild soap solution and soft cloth, rinse with water (avoid pressure washers)
- **Protection:** Use waterproof cover during extended harsh weather, store umbrella when not in use
- **Maintenance:** Apply outdoor wood sealant annually. Tighten metal fittings if loose.
- **Storage:** Keep slightly elevated off wet ground during winter months.

Product Usage Instructions

Cleaning:

1. Mix mild soap with water to create a cleaning solution.
2. Dampen a soft cloth with the solution.
3. Wipe down all surfaces of the product.
4. Rinse thoroughly with clean water.
5. Avoid using pressure washers as they may damage the product.

Protection:

1. During extended periods of harsh weather, cover the product with a waterproof cover.
2. When not in use, store the umbrella in a dry place to prevent damage.

Maintenance:

1. Annually apply outdoor wood sealant to protect the wood from weather elements.
2. Check and tighten any loose metal fittings to ensure stability and safety.

Storage:

1. Elevate the product slightly off the ground during winter months to prevent damage from moisture.
2. Store in a dry area when not in use to prolong its lifespan.

Warning:

Do not exceed weight limits of 500 lbs for benches and 200 lbs for tabletop. Exceeding these limits may result in damage to the product and pose a safety risk.

FAQ

Q: Can I use any type of wood sealant for maintenance?

A: It is recommended to use an outdoor-specific wood sealant that is suitable for the type of wood used in the product for optimal protection.

Q: How should I store the product during the off-season?

A: Store the product in a dry location, slightly elevated off the ground to prevent moisture damage, and ensure all metal fittings are tightened before storage.

Documents / Resources

	The Home Depot Wipe Surfaces with Mild Soap Solution and Soft Cloth [pdf] User Manual Wipe Surfaces with Mild Soap Solution and Soft Cloth, Mild Soap Solution and Soft Cloth, Solution and Soft Cloth, Soft Cloth
--	---

References

- [User Manual](#)

THE HOME
DEPOT

Mild Soap Solution and Soft Cloth, Soft Cloth, Solution and Soft Cloth, THE HOME DEPOT, Wipe Surfaces with Mild Soap Solution and Soft Cloth

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.