


THE RABBIT TRC-033 The Ears Plus Rabbit



THE RABBIT TRC-033 The Ears Plus Rabbit Instruction Manual

[Home](#) » [THE RABBIT](#) » THE RABBIT TRC-033 The Ears Plus Rabbit Instruction Manual 

Contents

- [1 THE RABBIT TRC-033 The Ears Plus Rabbit](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 OVERVIEW](#)
- [5 GETTING STARTED](#)
- [6 CONTROLLING YOUR RABBIT](#)
- [7 CHARGING](#)
- [8 VIBRATION PATTERNS](#)
- [9 HARE CARE](#)
- [10 SPECIFICATIONS](#)
- [11 DISPOSAL INFORMATION](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)
- [13 Related Posts](#)

THE
RABBIT

THE RABBIT TRC-033 The Ears Plus Rabbit



Product Information

Specifications

- **Materials:** Body Safe ABS / Silicone
- **Size:** 102x56x32 mm
- **Weight:** 65 g
- **Battery:** Li-ion 280 mAh
- **Charging Time:** 2 hours
- **Usage Time:** 1.5 hours

Product Usage Instructions

Getting Started

1. Before first use, charge your rabbit for approximately 2 hours using the provided USB charging cable.
2. Wash your rabbit with soap and water or a toy cleaner suitable for silicone items before and after each use.
3. If needed, apply a water-based, silicone-compatible lubricant to the rabbit.
4. Press and hold the power button for 3 seconds to turn the item ON.
5. To adjust vibration intensity, press the respective buttons.
6. To change vibration patterns, press the pattern button accordingly.
7. Press and hold the power button for 3 seconds to turn OFF.

Charging

Flashing Light indicates charging, while Solid Light means the rabbit is fully charged.

Care Instructions

1. Always clean your rabbit thoroughly before and after each use.
2. Use a premium water-based lubricant when needed; avoid silicone-based lubricants.
3. Clean with a suitable silicone-compatible toy cleanser or luke-warm water with antibacterial soap.
4. Avoid exposure to direct sunlight and extreme heat.
5. The rabbit is splashproof, not submersible; ensure it is completely dry before storage.

FAQs

- FAQs can be found at www.TheRabbitCompany.com
- Email us at customercare@TheRabbitCompany.com for any unanswered questions.

OVERVIEW

- All products by The Rabbit Company™ are made from soft, smooth, body-safe materials.
- Our easy-to-use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that can not be matched and will have you craving for more.

THE EARS PLUS RABBIT



External Stimulators


Vibration Function Button

DC Charging Port




GETTING STARTED


1. Before first use, charge your rabbit for approximately 2 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (Not included).
 - Flashing Light = Charging
 - Solid Light = Fully Charged
 - Rapid Flashing Light = Low battery, charge is needed







2. Wash your rabbit with soap and water, or toy cleaner suitable for use with silicone items.






3. Lubricate your rabbit (if needed) with a water-based, silicone-compatible lubricant.
4. Press the  for button for 3 seconds to turn the item ON.




5. To change the vibration intensity, press and release 
6. To change the vibration pattern, press, and release 
7. Press the  button for 3 seconds again to turn OFF.




CONTROLLING YOUR RABBIT

- Press the  button for 3 seconds to turn the item ON.
- To change the vibration pattern, press, and release 
- Press the  button for 3 seconds again to turn OFF.




CHARGING

- Insert the charging plug in the designated charging area
- Flashing light indicates item is charging
- Solid light indicates item is fully charged
- Rabbits require approximately 2 hours for full charge




Flashing Light = Charging



Solid Light = Fully Charged


VIBRATION PATTERNS



HARE CARE

Cleaning, Storage & Safety


1. Always clean your Rabbit thoroughly before and after each use.
2. We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the product. Never use hand cream, or massage oils as lubricants for your intimate areas.




3. To properly clean your rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your rabbit with lukewarm water and an antibacterial soap. Rinse clean and pat dry using a lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.



4. Avoid leaving your rabbit in direct sunlight and never expose it to extreme heat.



5. Splashproof Function: The rabbit is splashproof and is resistant to small amounts of liquid or splashing only, it is not submersible in water or other liquids. The rabbit is not intended for bath or shower use. Make sure to completely and thoroughly dry before storage. The device must not be submerged or be exposed to prolonged underwater exposure, this can lead to damage or failure of the product.



SPECIFICATIONS

- **Materials**

Body Safe ABS/Silicone

- **Size**

102x56x32 mm

- **Weight**

65 g

- **Battery**

Li-ion 280 mAh

- **Charging**

2 hours

- **Use Time**

1.5 hours

- **Max Noise Level**

<68 db

- **Interface**

12 modes


DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather

brought to the appropriate collection point for recycling electrical and electronic equipment.

Documents / Resources

| | |
|---|--|
|  | THE RABBIT TRC-033 The Ears Plus Rabbit [pdf] Instruction Manual TRC-033 The Ears Plus Rabbit, TRC-033, The Ears Plus Rabbit, Ears Plus Rabbit, Plus Rabbit, Rabbit |
|---|--|

References

- [The Rabbit Company](#)
- [The Rabbit Company](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.