THE SHARPER IMAGE 502080-04 Mosquito String Light Instruction Manual

THE SHARPER IMAGE 502080-04 Mosquito String Light Instruction Manual

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

1. Do not attempt to disassemble and repair the product yourself.
2. To avoid damage to your eyes, do not look directly at light source.
3. Waterproof level IP65, adapter only is IP44.

Contents

ASSEMBLY INSTRUCTIONS:

1. Remove all parts from packing material.
2. Insert cable part (F) onto the cable end marked (G) as shown in Diagram (C), and screw the cover (G) onto (F) and tighten.
3. Insert the other end of the cable (D) onto the cable end marked (C) as shown in Diagram (B), and screw the cover (C) onto (D) and tighten.
4. Insert the adapter (A) onto the cable (B) as shown in Diagram (A) and screw the cover (B) onto (A) and tighten.
5. Plug the adapter into the outlet.
6. Use the push button 3-way switch (E) on the cable to enjoy.
   **Push#1** – Yellow light for Mosquito repellent.
   Push#2 – White light for decorative lighting.
   **Push#3** – Whole string turns off.

C   **D**

F   **G**

CLEANING AND STORAGE

1. Always make sure the device is turned off before cleaning.
2. To clean, use a soft cloth.
3. Do not use any chemical or abrasive cleaners

Product Overview

The product has three key function:

White light (conventional white light illumination) /yellow light (mosquito repelient 575-580NM)/off

White/yellow (mosquito repellent effect)

1 meter a bulb

Controller to switch colors

 Anti mosquito effect

Longlasting protection

No side effects

Safe and reliable

Documents / Resources

THE SHARPER IMAGE 502080-04 Mosquito String Light [pdf] Instruction Manual
502080-04 Mosquito String Light, 502080-04, Mosquito String Light, String Light, Light