



THE SOURCE 108085215 Wireless Speaker with LED Light Instruction Manual

[Home](#) » [The Source](#) » THE SOURCE 108085215 Wireless Speaker with LED Light Instruction Manual 

WIRELESS SPEAKER WITH LED LIGHT Instruction Manual


Contents

- [1 INCLUDED](#)
- [2 COMPONENT IDENTIFICATION](#)
- [3 GETTING STARTED CHARGING](#)
- [4 PAIRING](#)
- [5 PLAY MUSIC](#)
- [6 PLAY MUSIC FROM YOUR PC OR LAPTOP](#)
- [7 LIGHT](#)
- [8 BATTERY LIFE](#)
- [9 TROUBLESHOOTING](#)
- [10 SPECIFICATIONS](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)

INCLUDED

- Wireless speaker with LED light
- Micro USB charging cable
- Instruction manual

COMPONENT IDENTIFICATION



1. LED
2. Charging LED
3. Micro USB charging port
4. Status LED
5. Increase volume/next song
6. Decrease volume/previous song
7. Play/pause
8. Light ON/OFF

GETTING STARTED CHARGING

Use the included charging cable to fully charge the speaker before first use. It will take approximately 4 hours to fully charge.

- The red LED will be ON while the speaker is charging
- Green LED will be ON once charging is complete

PAIRING

1. Turn the speaker ON by pressing a button. Blue LED will flash rapidly to indicate the speaker is in pairing mode
2. Turn the Bluetooth® ON in your device settings and select "Lighted Speaker".
3. Once paired successfully, the speaker will beep and the blue LED will flash slowly

If you fail to pair your device or you want to pair it with a new device please repeat the steps outlined above.

PLAY MUSIC



- Press and hold the + or – buttons to turn the volume up or down
- Press the + or – buttons to skip to the next or previous song
- Press the ►|| button to pause, press again to resume

PLAY MUSIC FROM YOUR PC OR LAPTOP

After pairing the device to your PC or laptop, right-click on the speaker icon on the lower right-hand corner of the

taskbar, select “Playback devices”. Under the “Playback” tab, the paired device will show within the list. To connect it, click on the device to set it as the default device. The audio will start to play from the paired device.

LIGHT

- Press the  button to turn the light ON and OFF
- Press and hold  button to adjust the brightness of the light

BATTERY LIFE

LIGHT	SPEAKER	HOURS
Max	OFF	10
OFF	Max	8.5
Max	Max	4.5

TROUBLESHOOTING

Problem	Solution
Music playback interrupting	Low battery, charge speaker
Cannot power ON	
Music is intermittent in Bluetooth playback	Move Bluetooth® devices closer to the speaker.
	Charge the speaker.
Device cannot pair with the speaker	Low battery, charge speaker
	Move Bluetooth® devices closer to the speaker.
	Turn the speaker OFF then back ON
	Confirm device/computer has Bluetooth' capabilities
	Try set up again
	Check to see if another device is already connected to the speaker. Disconnect and try pairing the device again.
	Bluetooth name is not correct, confirm selecting "Lighted Speaker"
Buttons don't work	Low battery, charge speaker
	Turn the speaker OFF then back ON
The speaker volume too low or too high	Press and hold + or – to adjust the volume to the desired level

SPECIFICATIONS

<p>Rated voltage:</p> <p>Rated current:</p> <p>Audio Max power:</p> <p>Max power consumption:</p> <p>Frequency response:</p> <p>Power supplied:</p> <p>Charging time:</p> <p>Play time:</p> <p>Nightlight:</p> <p>Play time with night light:</p>	<p>DC5V</p> <p>1500mA</p> <p>2.5W</p> <p>1W</p> <p>100Hz-20kHz</p> <p>built-in rechargeable lithium battery</p> <p>approx. 4 hours</p> <p>approx 3hours at max volume on a full charge</p> <p>approx 4 hours on a full charge</p> <p>approx 3hours at max volume on a full charge</p>
---	---

CAUTION

- Speaker is not waterproof, DO NOT leave out in the rain or in high temperatures



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

IC: 255A-8085215

Imported by:

The Source, Barrie, Ontario, Canada, L4M 4W5

Manufactured in China


www.thesource.ca

© 2020 The Source. All rights reserved.



Please Recycle

Documents / Resources



[THE SOURCE 108085215 Wireless Speaker with LED Light](#) [pdf] Instruction Manual
108085215, Wireless Speaker with LED Light