



THINKCAR THINKTOOL MAX Diagnostic Scan Tool Instruction Manual

[Home](#) » [THINKCAR](#) » THINKCAR THINKTOOL MAX Diagnostic Scan Tool Instruction Manual 

THINKCAR THINKTOOL MAX Diagnostic Scan Tool Instruction Manual




needed: a) After replacing the electronic control unit, the relevant characteristics of the throttle operation have not been stored in the electronic control unit. b) After the electric control unit is powered off, the memory of the electric control unit's memory is lost. c) After replacing the throttle assembly, you need to match the throttle. d) After replacing or disassembling the intake port, the controlling of the idle speed by the coordination between the electronic control unit and the throttle body is affected. e) Although the characteristics of the idle throttle potentiometer have not changed, the intake volume has changed and the idle control characteristics have changed at the same throttle openings.

Contents

1 Documents /
Resources

2 Related Posts

Documents / Resources

	<p>THINKCAR THINKTOOL MAX Diagnostic Scan Tool [pdf] Instruction Manual TOOLMAX, 2AUARTOOLMAX, THINKTOOL Platinum S20, THINKTOOL Euro Max, THINKTOOL MAX, Diagnostic Scan Tool, THINKTOOL MAX Diagnostic Scan Tool</p>
--	--