

THORN AFP2 S-M-L Large Spaces LED Projector Installation Guide


Home » THORN » THORN AFP2 S-M-L Large Spaces LED Projector Installation Guide The Projector Install






Contents

- 1 K Installation instructions
- 2 Documents / Resources
- 2.1 References
- **3 Related Posts**




Regulations Australia / New Zealand wind speeds 250 km/h Tilting limited :

The luminaire with clear optic should be positioned so that prolonged staring into the luminaire at a distance <1.5 m is not expected




	AFP2						
	QE" ⁴ – E	B mm	B1 mm	H mm	mm	H1W(kg)	SCx (at 90°)
S	375	285	145	62.5	208	7,6	0,165
М	389	435	145	62.5	208	10,6	0,223
L	389	585	145	62.5	232	14	0,285


1.




2. **AFP2 S-M-L**




3. **AFP2 S-M-L**




4. CLASS I Standard




5. CLASS I HFX









7. CLASS I BS




8. CLASS II Standard



10. CLASS II BPL/LRT







II=OFF


100%

12. **AFP2 S-M-L**




13. **AFP2 S-M-L**






15. **FP2 S-M-L**



16. **AFP2 L**




Replace any cracked protective shield. -Class II luminaires must be installed so that exposed metal work of the luminaire is not in contact with any part of the electrical installation connected to a protective conductor.

WARNING:

Class I luminaires must be

earthed. This luminaire operates at mains voltage which must be switched off before intervention in control gear. - Any modification to this luminaire is forbidden. -Lighted objects nearer than the minimal distance in the is forbidden.

Documents / Resources



THORN AFP2 S-M-L Large Spaces LED Projector [pdf] Installation Guide
AFP2 M 60L70-740 A4 CL2 GY, AFP2 S-M-L, AFP2 S-M-L Large Spaces LED Projector, Large
Spaces LED Projector, Spaces LED Projector, LED Projector, Projector

References

User Manual

Manuals+, Privacy Policy