

# **THROWBACK TWIST N'SHOUT Vintage Wireless Speaker Instruction Manual**

Home » THROWBACK » THROWBACK TWIST N'SHOUT Vintage Wireless Speaker Instruction Manual





**Operation Manual** 


### **Contents**

- **1 PRODUCT DIAGRAMS**
- **2 FUNCTION INTRODUCTION**
- **3 SPECIFICATIONS**
- **4 CONTENTS**
- **5 INTERNAL BATTERY CARE**
- **6 PAIRING BLUETOOTH**

**SPEAKER** 

- **7 SAFE TY GUIDELINES**
- **8 FCC STATEMENT**
- 9 Documents / Resources
- **10 Related Posts**

# **PRODUCT DIAGRAMS**



# **FUNCTION INTRODUCTION**

- 1. Tone arm ON/OFF switch
- 2. Spinning recod spins when music is playing
- 3. Mode switch
- 4. Indicator light
- 5. Charging port
- 6. Audio controls

Rotate: adjust volume

Single press: next track

Doulbe press: previous track,

Long press: pause/play

a) In Bluetooth mode

i. Rotate left to decrease the volume

- ii. Rotate ight for volume increase
- iii. Short press next song
- 7. iv. Double click the previous song
  - v. Long pess for 2 seconds to pause/play
  - b) Telephone call
  - i. Short press to answe the incoming call
  - ii. Short press to hang up while on a call
  - iii. Long press to eject the incoming call
  - c) In FM mode
  - i. Rotate left to decrease the volume
  - ii. Rotate ight for volume increase
  - iii. pess and hold for 3 seconds to search for the radio station and memorize it
  - iv. Short press to jump to the next station in memory
  - v. Double click to jump to the previous station in memory
- 8. AUX Jack

### **SPECIFICATIONS**

Bluetooth· version: 5.1 Baery: 3.7V/300mAh Charging Time: 3h5

Input parameter: DC SV 1A Loudspeake:40mm4Q3W Blurtooth link range: 10 meters Product size: 105 x 110 x 92mm

Weight: 0.688 lb/0.312 kg FCC ID: 2BBPLTBVNYL

#### **CONTENTS**

- Vintage Vinyl speaker
- · Micro USB charging cable
- User manual
- 3.5mm Audio cable

# **INTERNAL BATTERY CARE**

- Be sure ta charge the speaker fully, before use
- Do not overcharge Charging takes 2-3 hours, overcharging may severely affect battery life
- Speaker may lose charge if not used for a long period.
- · Only use included cable for charging this device
- Indicator light will turn red when charging and tum off when fully charged

## PAIRING BLUETOOTH SPEAKER

1. To pair the device, turn the mode switch to Bluetooth. The speaker will automatically await pairing.

- 2. From your smartphone or tablet, find a list of nearby devices and choose "TB-VNYL"
- 3. Enter "0000" if asked. The speaker will "beep" when the pairing is complete If the speaker has been paired prior, it will connect automatically.

### **SAFE TY GUIDELINES**

Please ead fhe instruction caefully before use and keep them for eference.

- Keep the speake away from heat and open fire.
- Do not insert sharp objectand metal into the speaketo avoid a short circuit.
- · Do not aempf to epair fhe speaker .
- Tum the device off if exposed to extreme heat or liquid.
- Do not aempt to use the speaker with AC input, be sure the device is unplugged from power and charged before each use.

#### PAIRING BLUETOOTH SPEAKER

- 1. Ta pair the device, turn the mode switch to Bluetooth The speaker will automatically await pairing
- 2. From your smartphone or tablet, find a list of nearby devices and choose "TB-VNYL"
- 3. Enter "0000" if asked. The speaker will "beep" when the pairing is complete If the speaker has been paired prior, it will connect automatically.

#### **SAFETY GUIDELINES**

Please read the instruction carefully before use and keep them for reference.

- Keep the speaker away from heaf and open fire.
- Do not insert sharp objects and metal into the speaker to avoid a short circuit.
- Do not aempt fo repair the speaker
- Turn the device off if exposed to extreme heaf or liquid.
- Do not aempt fo use the speaker with AC input, be sure the device is unplugged from power and charged before each use

## **FCC STATEMENT**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible forcompliance could void the users authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pur.;uant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to ITy to correct the interference by one or more of the following measures:

- Reorient o elocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different!om that to which the receiver is connected.
- Consult the dealer or an experienced radio/N technician for help.

# **FCC RADIATION EXPOSURE STATEMENT**

This equipment complies with FCC radon exposure limits set forth for anuncontrolled environment.



### **Documents / Resources**



THROWBACK TWIST N'SHOUT Vintage Wireless Speaker [pdf] Instruction Manual 2BBPLTBVNYL, 2BBPLTBVNYL, TWIST N SHOUT Vintage Wireless Speaker, Vintage Wireless Speaker, Wireless Speaker, Speaker

Manuals+,