

# **THRUSTMASTER Firestorm Digital 3 USB Controller User Guide**

Home » THRUSTMASTER » THRUSTMASTER Firestorm Digital 3 USB Controller User Guide 🖫




### **Contents**

- 1 Firestorm Digital 3 USB Controller
- **2 TECHNICAL FEATURES**
- 3 PC SETUP
- 4 Documents / Resources
  - **4.1 References**

**Firestorm Digital 3 USB Controller** 



# **TECHNICAL FEATURES**



- 1. 8 action buttons
- 2. 8-way D-Pad

For PCs (Windows 98 or higher) equipped with USB ports.

#### PC SETUP

The USB connector allows you to hot-plug your Firestorm Digital 3 Gamepad directly into your computer.

 Start your computer up and plug the USB connector into one of the USB ports located at the back of your computer.

Windows 98/Me/2000/XP will then automatically detect the new peripheral device.

**Note:** if you are connecting a USB peripheral device for the first time, Windows may ask you for the Windows CD-ROM during installation in order to install the required system files.

Under Windows 98: the Add New Hardware Wizard will find the appropriate drivers for you. Simply click on Next and then follow the on-screen instructions to complete the installation.

Under Windows Me/2000/XP: installation of the drivers is carried out automatically.

2. To ensure that the gamepad has been properly installed, click on Start/Settings/Control Panel, then double-click on the Game Controllers icon.

If the gamepad has been installed correctly, it will appear in the list of game controllers, with OK status.

**Note:** in the event of malfunction during use due to electrostatic emission, please exit the game and unplug the unit from your computer. Resume normal game play by plugging the unit back in and restarting the game. © Guillemot Corporation 2001. All rights reserved. Thrustmaster® and Firestorm™ are trademarks and/or registered trademarks of Guillemot Corporation S.A. Microsoft® Windows® and DirectX® are registered trademarks of Microsoft Corporation in the United States and/or other countries. All other trademarks and brand names are hereby acknowledged and are property of their respective owners. Illustrations not binding. Contents, desgns and specfcations are subject to change without notice and may vary from one country to another.



#### **Documents / Resources**



THRUSTMASTER Firestorm Digital 3 USB Controller [pdf] User Guide Firestorm Digital 3 USB Controller, Firestorm, Digital 3 USB Controller, 3 USB Controller, USB Controller, Controller

## References

- Manual-Hub.com Free PDF manuals!
- User Manual

SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsemen	t.