

TiGHT AV SPK1-C650T-WH 2-Way Ceiling Speaker User Manual

Home » TIGHT AV » TIGHT AV SPK1-C650T-WH 2-Way Ceiling Speaker User Manual



User Manual SPK1-C650T-WH 6,5" 2-Way Ceiling Speaker, 70/100V and 80hm, 50W RMS

All Rights Reserved Version: SPK1-C650T_2022V1.0

Contents

- 1 Statement
- **2 Safety Precaution**
- **3 Customer Service**
- 4 Introduction
- **5 Features**
- **6 Specifications**
- 7 Package List
- 8 Installation
- 9 Documents /

Resources

10 Related Posts

Statement

Read this user manual carefully before using this product. Pictures shown in this manual are for reference only, different model and specifications are subject to real product. This manual is for operation instruction only, not for any maintenance usage. The functions described in this version are updated by November 2022. In the constant

effort to improve our product, we reserve the right to make functions or parameters changes without notice or obligation. Please refer to your distributor for the latest details.

Safety Precaution

To ensure the best from the product, please read all instructions carefully before using the device. Save this manual for further reference.

- Using supplies or parts not meeting the products' specifications may cause damage, deterioration or malfunction.
- Do not expose the unit to rain, moisture or install this product near water.
- Do not use liquid or aerosol cleaners to clean this unit.
- · Refer all servicing to qualified service personnel.
- Prior to installing the speakers into any ceiling/wall, check the structure for weight bearing ability and avoid contact with any wiring or plumbing that might be behind the surface area. Installing on soft materials or in areas incapable of supporting the speakers weight may cause personal injury or damage to the speaker.
- Make sure the speaker is properly secured to the ceiling/wall. Please use the proper screws, bolts, or anchors. Failure to do so may cause the speaker to become unsecured and cause potential damages/injuries.
- Damage to the woofer and tweeter may occur if the speaker is dropped or hit and resulting in no sound or distorted sound.
- Never overdrive your speakers to the point of distortion and always reduce volume prior to switching input sources.
- Use only approved and certified wiring in your installation, do not stretch or place the wire in contact with sharp objects.
- Prior to removing cables ensure all power to your amplifier and other components is turned off.

Customer Service

We provide limited warranty for the product within five years counting from date of purchase (The purchase invoice shall prevail).

Note: Please contact your distributor immediately if any damage or defect in the components is found.

Introduction

The TiGHT AV SPK1-C650T-WH is a full-range coaxial ceiling speaker consisting of a 6.5 inch polypropene cone and a 0.5 inch mylar dome tweeter. It features combined 70V/100V and low impedance operation mode. The ceiling speaker also features easy-toinstall spring clamps "dog-legs" and a white flat magnetic grille.

Features

- 6.5 inch polypropylene cone driver with rubber edge
- 0.5 inch mylar dome tweeter
- Supports both 70V/100V and low impedance operation
 - 70V: 1.25W-2.5W-5W-10W & 8
 - 100V2.5W-5W-10W-15W & 8
- · Magnetic flat grille that comes in white color.


Specifications

RMS Power	50W
Impedance	8Ω (in low-impedance setting)
Sensitivity(1m/1W)	88dB
Max SPL (1m)	105dB (low-impedance)*
Frequency Range (-10dB)	65Hz-20kHz
Woofer Type	6.5" Polypropylene cone with rubber edge
Tweeter Type	0.5"(13mm) Mylar dome tweeter
Crossover Slope	6dB/Octave
Dimension	Ф227X103mm
Cutout Size	Ф210mm
Ceiling Thickness	Spring clamps can support up to 30mm ceiling thickness
Net Weight	1.25 kg
Shipping Weight	1.50 kg
Grille	Magnetic round grille. Color: White
Transformer	Knob Style 70V 1.25W-2.5W-5W-10W & 8Ω, 100V 2.5W-5W-10W-15W & 8Ω
Environmental Compliance	RoHS
Warranty	Limited 5 years warranty

^{*} Half-space (in ceiling)

Package List

Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact your distributor for a replacement.



Installation


① Cut the speaker hole

Use a stud finder to locate an area that is free of obstructions or studs. Position the cutout template where you

are installing the speaker. Trace the template to mark out the speaker location with a pencil. Drill a pilot hole and cut all of the way around the circular outline with a cutting saw.

② Set the operation mode


Use the knob located on the backside of the speaker to select operation mode and tap settings for 70V/100V mode.



	С	1	2	3	4
100V	8ohm	15W	10W	5W	2.5W
70V	8ohm	10W	5W	2.5W	1.25W


3 Connect speaker cable

Ensure that the amplifier is not connected or turned off before connecting speaker cables. Pull the speaker cable out of the hole which you have cut and connect it to the speaker.




4 Install the speaker

Set the spring clamps "dog-legs" aside and place the speaker into the ceiling. Then use the screwdriver and gently tighten the four screws on the front of the speaker to secure the speaker. Do not apply to much force as this can break the spring clamps.



S Attach the magnetic grille

As several magnets are on the speaker frame, attach the grille to the rim of the speaker directly. Ensure the grill is attached to the speaker securely to keep the grille from falling.



Note: Anytime you note distortion, reduce the volume. Never allow your amplifier to be driven into "clipping". Otherwise, the speakers may be damaged. Damage caused by operating the speakers at distorted volume levels is not covered by the warranty.

Documents / Resources

TIGHŢ	
User Manual SPK: CARDY WH 47 Was Game, Turker or date, SWMM	TiGHT AV SPK1-C650T-WH 2-Way Ceiling Speaker [pdf] User Manual SPK1-C650T-WH 2-Way Ceiling Speaker, SPK1-C650T-WH, 2-Way Ceiling Speaker, Ceiling Speaker, Speaker
of Option Recovery many Allerton (Allerton	

Manuals+,