


TimaCam App User Manual


[Home](#) » [TimaCam](#) » TimaCam App User Manual



Contents [[hide](#)]

- [1 TimaCam App](#)
- [2 How to Enable WIFI on your 2nd Gen Pinnacle Dash Cam](#)
- [3 How to connect to WIFI enable devices to your dash camera](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

TimaCam App




How to Enable WIFI on your 2nd Gen Pinnacle Dash Cam

1. Make sure dash cam is not recording.
2. Touch anywhere on the screen until you see WIFI symbol on the bottom menu.
3. Touch the WIFI signal to activate WIFI from your dash camera. Continue to next step.

How to connect to WIFI enable devices to your dash camera

1. Search and install TimaCam App in the App store or Google Play Store
2. Next Open your Network WIFI Settings and Select:
3. NVT_CARDV...network or similar (your dash cam may be different than what is shown)
4. Enter Password: 12345678
5. Next, Open TimaCam app and the device will automatically connect to your dash camera. (Make sure the dash cam and device connecting are near each other)

Documents / Resources

 <p>How to Enable WIFI on your Dash Cam Personal Dash Cam How to connect to WIFI enable devices to your dash camera</p>	<p>TimaCam TimaCam App [pdf] User Manual</p> <p>TimaCam App, App</p>
---	--