

TIME **TIMER**
**TTM9-HPP-W 60-
Minute Kids
Visual Timer**



TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer User Manual

[Home](#) » [TIME-TIMER](#) » TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer User Manual 

Contents

- [1 TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer](#)
- [2 Introduction](#)
- [3 Specifications](#)
- [4 Package Include](#)
- [5 Features](#)
- [6 How to Install](#)
- [7 Usage](#)
- [8 Care and Maintenance](#)
- [9 Troubleshooting](#)
- [10 Pros and Cons](#)
- [11 Contact Information](#)
- [12 Warranty](#)
- [13 FAQs](#)
- [14 References](#)
- [15 Related Posts](#)



TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer



Launch Date: October 21, 2022

Price: \$44.84

Congratulations on the purchase of your new MOD. We hope that it helps you make every moment count!

Introduction

The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer is a very useful tool that can help both kids and adults better manage their time. This clever timer has a visible countdown that is shown by a red disk that slowly fades away as time goes by. This makes it easy for users to see how much time has passed at a glance. The TIME TIMER is great for schools, houses, and workplaces because it creates a clear visual cue that helps people focus and get things done. It works quietly so there are no distractions, and the available audio alert lets you know when the time is up gently. With its strong, long-lasting build and simple, easy-to-use design, this timer is great for keeping track of activities, routines, and jobs. The TIME TIMER TTM9-HPP-W is an essential tool for anyone who wants to get better at managing their time, whether they are doing chores, cooking, or going to meetings.

Specifications

- **Brand:** TIME TIMER
- **Model:** TTM9-HPP-W
- **Color:** White/Red
- **Material:** Plastic
- **Dimensions:** 7.5 x 7.25 x 1.75 inches
- **Weight:** 0.4 pounds
- **Power Source:** Battery-operated (requires 1 AA battery, not included)
- **Duration:** 60 minutes
- **Display Type:** Analog
- **Additional Color:** Peony Pink

- **Material Type:** Cotton (for cover)
- **Additional Dimensions:** 3.47 x 2.05 x 3.47 inches
- **Additional Weight:** 3.52 ounces

Package Include

- 1 x TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer
- Instruction Manual

Features


- **Easy to Use** The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer features a simple dial to set the desired time, making it straightforward for children to operate independently. The intuitive design ensures that even young kids can manage time effectively without adult supervision.
- **Visual Countdown** The red disk on the timer provides a clear visual countdown as it decreases, giving an immediate and easy-to-understand indication of the remaining time. This feature is particularly beneficial for visual learners and those who struggle with abstract concepts of time.
- **Silent Operation** Unlike traditional timers, this model operates silently without any ticking noise, making it ideal for quiet environments such as classrooms, libraries, or study areas. The silent operation ensures that children and adults can focus on their tasks without any auditory distractions.
- **Audible Alert** The timer includes an optional audible alert, which emits a gentle beep when the set time expires. This feature can be turned off for sound-sensitive environments, allowing users to avoid interruptions and maintain their focus.
- **Portable Design** With its lightweight and compact build, the TIME TIMER TTM9-HPP-W is easy to carry and place anywhere it's needed. Whether at home, school, or on the go, this portable design ensures that effective time management is always within reach.
- **Durable Construction** Made from sturdy plastic, the timer is designed to withstand daily use. Its robust construction ensures longevity, making it a reliable tool for managing time over the years.
- **Time Management** The 60-minute learning clock aids in organization and concentration across various tasks. It's perfect for improving time management and productivity in children and adults, helping them complete activities efficiently and within set timeframes.
- **Special Needs** The visual countdown timer is intuitively understood by people of all ages and abilities, including those with autism, ADHD, or other learning disabilities. It provides a calm transition between activities and eases workloads during stressful situations, making it a valuable tool for special needs education.
- **Removable Silicone Covers** The timer features four different removable silicone covers (sold separately) that encourage a creative and energetic environment for all ages. Each color can be assigned to different activities, such as gym time, homework, kitchen tasks, study sessions, or work, enhancing the timer's versatility.
- **Optional Audible Alert** The optional audible alert feature is designed for sound-sensitive environments to avoid distractions and interruptions. This option is ideal for projects, reading, studying, or taking tests, providing flexibility in different settings.
- **Product Details** The timer requires 1 AA battery (not included) and is available in multiple colors: Cotton Ball White, Lake Day Blue, Dreamsicle Orange, Pale Shale, Fern Green, and Peony Pink (sold separately). TIME TIMER has been a globally recognized time management resource for 25 years, known for helping kids and adults alike manage time effectively.



- **Calming Colors and Mix & Match Options** These colors not only express style but can also impact mood, creating either a calming or energizing environment. This can be particularly beneficial for those with attention differences or anxiety. The colors available for the timer include Lake Day Blue, Dreamsicle Orange, Fern Green, Peony Pink, Cotton Ball White, and Pale Shale.
- **1% for Inclusive Education Initiatives** For every Time Timer MOD Home Edition sold, TIME TIMER donates 1% of the revenue to support inclusive education initiatives. These donations help provide educational opportunities to all people, regardless of age, race, or cognitive and physical ability.
- **Protective Cases** Durable silicone covers (sold separately) offer protection and personalization for the timer. Available in various color packs, these covers can signify different tasks or family members, adding functionality and style.
- **Improved Functionality and Durability** The timer's easy-to-use battery compartment requires no screws or added parts, making it simple to insert a new AA battery when needed. The durable design and protective cases ensure the timer's longevity and adaptability to any room in the home.

Additional Features

- An on/off switch for the audible alert allows you to choose whether or not to hear the beep at the end of the timing cycle.
- The timer features a glare-free lens that protects the colored disk.
- The compact size of 3.5" x 3.5".




- Requires one AA battery for operation (not included).

How to Install

1. INSTALL ONE AA BATTERY

If your Time Timer MOD has a screw on the battery compartment, you'll need a mini Phillips head screwdriver to open and close the battery compartment. Otherwise, simply lift the battery cover to insert the battery into the compartment.



2. CHOOSE YOUR SOUND PREFERENCE

The timer itself is quiet—no distracting ticking sound—but you can choose whether or not to have an alert sound when time is complete. Simply use the on/off switch on the back of the timer to control audio alerts.

3. SET YOUR TIMER

Turn the center knob on the front of the timer counter-clockwise until you reach your chosen amount of time. Immediately, your new timer will begin to countdown, and a quick glance will reveal the time left thanks to the brightly colored disk and large, easy-to-read numbers.



BATTERY RECOMMENDATIONS

We recommend using high-quality, name-brand alkaline batteries to ensure accurate timing. You may use rechargeable batteries with Time Timer, but they may deplete more quickly than traditional batteries. If you do not plan to use your Time Timer for an extended period (several weeks or more), please remove the battery to avoid corrosion.

PRODUCT CARE

Our timers are manufactured to be as durable as possible, but like many clocks and timers, they have a quartz crystal inside. This mechanism makes our products quiet, accurate and easy to use, but it also makes them sensitive to being dropped or thrown. Please use it with care.

Usage

1. **Setting the Timer:** Turn the dial clockwise to set the desired time up to 60 minutes on the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer.
2. **Starting the Countdown:** Once the time is set, the red disk will begin to decrease, providing a visual representation of the time left.
3. **Using the Audible Alert:** If an audible alert is preferred, ensure the sound switch on the back of the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer is turned on. The timer will emit a gentle beep when the time is up.
4. **Silent Operation:** For silent operation, simply turn off the sound switch to disable the audible alert.
5. **Portable Use:** The lightweight and compact design of the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer allows it to be easily moved and used in various locations such as classrooms, homes, and workplaces.
6. **Special Needs Application:** The visual countdown feature is especially beneficial for individuals with special needs, providing a clear and understandable way to manage time.
7. **Multiple Activities:** Use different removable silicone covers (available separately) to assign the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer to specific activities like homework, cooking, studying, or working.
8. **Adjusting Time Intervals:** Turn the center knob on the front of the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer counterclockwise to reset or adjust the time interval as needed.
9. **Visual Cue:** The visual cue of the red disk disappearing helps users stay aware of the passing time, enhancing focus and productivity.
10. **Managing Routines:** Incorporate the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer into daily routines to manage time more effectively and reduce stress.

Care and Maintenance

1. **Battery Replacement:** When the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer stops working or the alert sound becomes weak, replace the AA battery. Open the battery compartment on the back, remove the old battery, and insert a new one.
2. **Cleaning:** Wipe the surface of the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer with a soft, damp cloth. Avoid using harsh chemicals or submerging the timer in water.
3. **Storage:** Store the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer in a cool, dry place when not in use to prolong its lifespan.
4. **Handling:** Handle the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer with care to avoid dropping or exposing it to excessive force, which could damage the internal mechanisms.
5. **Sound Switch Maintenance:** Periodically check the sound switch to ensure it operates correctly. If the switch becomes loose or fails to work, gently adjust it or consult customer service for assistance.
6. **Visual Disk Maintenance:** Ensure the red disk moves smoothly without obstruction. If the disk becomes stuck, gently tap the timer to see if it resumes movement.
7. **Mechanical Issue Resolution:** If the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer experiences mechanical issues, such as the timer not starting or stopping prematurely, consult the troubleshooting guide or contact customer service for help.
8. **Protective Covers:** Use the optional silicone covers to protect the timer from minor bumps and scratches. These covers also allow for customization and assigning the timer to specific tasks or users.
9. **Calibration:** If the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer is not displaying the correct time, recalibrate it by turning the dial to zero and resetting it.
10. **Regular Checks:** Regularly check the timer for any signs of wear or damage, and address any issues promptly to ensure the timer continues to function correctly.

Troubleshooting

Issue	Possible Cause	Solution
The timer does not start	Battery is dead or not installed	Replace or install a new AA battery
No audible alert when time is up	The sound function is turned off	Check the sound switch and ensure it is turned on
The timer stops before reaching zero	The dial not set correctly	Ensure the dial is turned fully to the desired time
The red disk not moving	Mechanical issue	Gently tap the timer to see if it resumes movement
Timer is noisy	Internal mechanism issue	Contact customer service for further assistance
The timer is not displaying the correct time	The dial is not calibrated	Recalibrate by turning the dial to zero and resetting
Battery compartment cover loose	The cover is not properly closed	Ensure the cover is securely fastened
Timer resetting unintentionally	Weak battery connection	Check and adjust the battery connection or replace the battery

Pros and Cons

Pros:

- Visually engaging for kids
- Durable silicone case
- Customizable with additional case colors
- Compact and portable design

Cons:

- Battery not included
- Limited to 60-minute intervals

Contact Information

For any inquiries or support, please contact Time Timer at support@timetimer.com or visit their website at www.timetimer.com.

Warranty

The TIME TIMER TTM9-HPP-W comes with a One-Year 100% Satisfaction Guarantee, ensuring your satisfaction with the product.

FAQs

What is the main feature of the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer?

The main feature of the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer is its visual countdown, represented by a red disk that gradually disappears as time progresses.

How long can the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer be set for?

The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer can be set for up to 60 minutes.

What type of display does the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer use?

The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer uses an analog display.

What power source does the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer require?

The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer requires one AA battery for operation.

What materials is the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer made from?

The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer is made from durable plastic.

How portable is the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer?

The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer is lightweight and compact, making it highly portable.

What additional colors are available for the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer?

The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer is also available in Peony Pink and other colors that can be purchased separately.

What are the dimensions of the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer?

The dimensions of the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer are 7.5 x 7.25 x 1.75 inches.

How does the visual countdown on the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer work?

The visual countdown on the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer works by the red disk gradually decreasing as the set time elapses, providing a clear indication of the remaining time.

Where can the TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer be used?

The TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer can be used in various settings, including classrooms, homes, workplaces, and any other environment where time management is needed.

Download this Manual: [TIME TIMER TTM9-HPP-W 60-Minute Kids Visual Timer User Manual](#)

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.