

TIME TIMER TT120-W Minute Desk Visual Timer User Manual

Home » TIME TIMER » TIME TIMER TT120-W Minute Desk Visual Timer User Manual



Contents

- 1 TIME TIMER TT120-W Minute Desk Visual Timer
- 2 Introduction
- 3 Specifications
- **4 Package Includes**
- **5 Features**
- **6 INSTALL ONE AA BATTERY**
- 7 Usage
- **8 Care and Maintenance**
- 9 Troubleshooting
- 10 Pros and Cons
- **11 Contact Information**
- 12 Warranty
- 13 FAQs
- 14 Video-TIME TIMER TT120-W Minute Desk Visual

Timer

- 15 References
- **16 Related Posts**



TIME TIMER TT120-W Minute Desk Visual Timer



Launch Date: April 2, 2022

Price: \$40.95

Introduction

The TIME TIMER TT120-W Minute Desk Visual Timer is a great tool for getting better at managing your time. This timer is great for use in classrooms, offices, and personal areas because it shows time visually, which helps people stay on task and organized. One clever feature of the simple but original design is a red disk that slowly fades away over time, making it easy to see how much time is left. It is perfect for places that need to be quiet and have few distractions because it works quietly. The timer can be set to any length of time up to 120 minutes, so it can be used for a wide range of chores and activities. Its small and portable size makes it easy to use on desks, countertops, and other flat areas. It's made of strong plastic, so it should last a long time and work well. The TIME TIMER TT120-W runs on batteries, which makes it easy to use and convenient. This visual timer is a great way to get more done, whether you are managing a busy plan, running a meeting, or helping kids learn how to manage their time.

Specifications

• Brand: TIME TIMER

• Model: TT120-W

Color: WhiteMaterial: Plastic

• Power: Battery operated (1 AA battery required, not included)

Item Weight: 3.2 ouncesDisplay Type: Analog

Package Includes

• 1 x TIME TIMER TT120-W Minute Desk Visual Timer

· Instruction manual

Features

Visual Time Management

- **Description:** The TIME TIMER TT120-W Minute Desk Visual Timer uses a red disk to visually represent the passage of time. As the set time elapses, the red disk gradually decreases, providing a clear and intuitive visual cue of the remaining time.
- Benefit: This feature helps users stay aware of the time, improving their ability to manage tasks efficiently.

Silent Operation

- **Description:** The timer operates without producing any ticking sound, ensuring a quiet environment.
- **Benefit:** Ideal for settings where silence is important, such as classrooms, offices, libraries, and during study sessions.

Customizable Time Range

- Description: The timer allows users to set any time interval up to 120 minutes.
- Benefit: This flexibility makes it suitable for a wide range of activities, from short tasks to longer sessions.

Compact Design

- **Description:** The timer is portable, with dimensions of 5.5 x 7 inches, and can easily fit on desks, countertops, and other surfaces.
- Benefit: Its compact size and portability allow users to carry and use it in various locations.

Durable Construction

- **Description:** Made from high-quality plastic, the TIME TIMER TT120-W Minute Desk Visual Timer is built to last
- Benefit: Ensures long-term reliability and durability, making it a worthwhile investment.

Time Management

- **Description:** The 120-minute visual timer aids in enhancing time management and productive learning by keeping users on track with their activities.
- Benefit: Especially useful for time-outs, workouts, and structured learning environments.

Special Needs

• **Description:** The visual timer is designed to encourage organization and productivity for all ages, including those with autism, ADHD, or other learning disabilities. It helps create a visual schedule that assists in transitioning between activities.

• Benefit: Supports individuals with special needs in managing their time and activities more effectively.

Easy-to-Use

- **Description:** The timer features an analog design with a portable handle, a protective lens, and a center-set knob for easy adjustment. It is available in 5, 20, 60, and 120-minute durations.
- **Benefit:** Facilitates straightforward usage in various settings such as desks, kitchens, or gyms, making it adaptable to different routines.



Optional Audible Alert

- **Description:** The countdown clock offers an optional alarm along with silent operation.
- **Benefit:** Users can choose to use the audible alert for activities where a sound notification is needed, such as cooking or workouts, while silent operation is ideal for studying or reading.

Product Details

• **Description:** The timer measures 5.5 x 7 inches and requires 1 AA battery (not included). The battery compartment is securely enclosed with a small screw to meet CPSIA standards, requiring a mini Phillips head screwdriver to open/close.

• **Benefit:** Ensures safety and compliance with standards, transcending language, and cultural barriers by providing a universal visual tool for time management

INSTALL ONE AA BATTERY

If your Time Timer® PLUS has a screw on the battery compartment, you'll need a mini Phillips head screwdriver to open and close the battery compartment. Otherwise, simply open the battery cover down to insert the battery into the compartment.



CHOOSE YOUR SOUND PREFERENCE

The timer itself is quiet—no distracting ticking sound—but you can choose the volume and whether or not to have an alert sound when time is complete. Simply use the volume-control dial on the back of the timer to control audio alerts



SET YOUR TIMER

Turn the center knob on the front of the timer counter-clockwise until you reach your chosen amount of time.

Immediately, your new timer will begin to countdown, and a glance will reveal the time left thanks to the brightly colored disk and large, easy-to-read numbers.



BATTERY RECOMMENDATIONS

We recommend using high-quality, name-brand alkaline batteries to ensure accurate timing. You may use rechargeable batteries with Time Timer®, but they may deplete more quickly than traditional batteries. If you do not plan to use your Time Timer® for an extended period (several weeks or more), please remove the battery to avoid corrosion.

PRODUCT CARE

Our timers are manufactured to be as durable as possible, but like many clocks and timers, they have a quartz crystal inside. This mechanism makes our products quiet, accurate, and easy to use, but it also makes them sensitive to being dropped or thrown. Please use it with care.

Usage

- Setting the Timer: Turn the dial to set the desired time interval. The red disk will move accordingly.
- Starting the Timer: Once set, the timer starts automatically, and the red disk begins to decrease.
- Time Up: When the set time has elapsed, an audible beep will sound to alert the user.

Care and Maintenance

- Battery Replacement: Replace the AA battery when the timer starts to slow down or stops working.
- Cleaning: Wipe the timer with a soft, dry cloth. Avoid using water or cleaning agents directly on the device.
- Storage: Store the timer in a cool, dry place when not in use to prevent damage.

Troubleshooting

Issue	Possible Cause	Solution
Timer not working	Dead or missing battery	Replace or insert a new AA battery
Timer not beeping	Low battery	Replace the battery
The red disk not moving	The timer is not set properly	Ensure the dial is turned fully
Timer is noisy	Internal mechanism issu e	Contact customer support for repair
Timer stops abruptly	Battery connection issue	Check battery contacts and reposition
The timer not resetting cor rectly	Mechanical issue	Manually reset the dial and try again
The timer display is unclea	Dirt or debris on display	Clean the display with a soft, dry cloth
Difficulty setting time	Stiff dial	Rotate the dial gently to avoid damage
Inconsistent countdown	Faulty timer mechanism	Contact customer support for assistance
Battery drains quickly	Faulty battery or connections	Use a new, high-quality AA battery and ensure proper installation

Pros and Cons

Pros:

- Visual representation of time enhances understanding.
- Quiet operation is ideal for various settings.
- Portable and easy to use.

Cons:

- Requires batteries, which need to be replaced periodically.
- Some users may prefer a digital display for precise time settings.

Contact Information

For further inquiries, you can reach Time Timer customer service at their official website or through their customer support email.

• Email Support: support@timetimer.com

Warranty

The TIME TIMER TT120-W comes with a **one-year 100% satisfaction guarantee**, ensuring you can purchase with confidence. If you encounter any issues within this period, you can return the product for a full refund or replacement.

Congratulations on the purchase of your new Time Timer® PLUS. We hope that it helps you make every moment count

FAQs

What is the primary function of the TIME TIMER TT120-W Minute Desk Visual Timer?

The primary function of the TIME TIMER TT120-W Minute Desk Visual Timer is to provide a visual representation of time, helping users manage their tasks more effectively.

What is the primary function of the TIME TIMER TT120-W Minute Desk Visual Timer?

The primary function of the TIME TIMER TT120-W Minute Desk Visual Timer is to provide a visual representation of time, helping users manage their tasks more effectively.

How does the TIME TIMER TT120-W Minute Desk Visual Timer display time?

The TIME TIMER TT120-W Minute Desk Visual Timer displays time through a red disk that gradually decreases as the set time elapses, providing a clear visual cue of the remaining time.

What is the maximum time interval that can be set on the TIME TIMER TT120-W Minute Desk Visual Timer?

The maximum time interval that can be set on the TIME TIMER TT120-W Minute Desk Visual Timer is 120 minutes.

What type of power source does the TIME TIMER TT120-W Minute Desk Visual Timer use?

The TIME TIMER TT120-W Minute Desk Visual Timer uses a single AA battery as its power source.

What are the dimensions of the TIME TIMER TT120-W Minute Desk Visual Timer?

The dimensions of the TIME TIMER TT120-W Minute Desk Visual Timer are 3.6 x 1.5 x 3.6 inches.

How do you set the desired time on the TIME TIMER TT120-W Minute Desk Visual Timer?

To set the desired time on the TIME TIMER TT120-W Minute Desk Visual Timer, turn the dial to the required time interval, and the red disk will adjust accordingly.

What happens when the set time on the TIME TIMER TT120-W Minute Desk Visual Timer elapses?

When the set time elapses on the TIME TIMER TT120-W Minute Desk Visual Timer, an audible beep will sound to alert the user.

What type of display does the TIME TIMER TT120-W Minute Desk Visual Timer have?

The TIME TIMER TT120-W Minute Desk Visual Timer has an analog display, featuring a red disk that visually represents the remaining time.

How can you maintain the TIME TIMER TT120-W Minute Desk Visual Timer?

To maintain the TIME TIMER TT120-W Minute Desk Visual Timer, replace the AA battery when needed, clean it with a soft, dry cloth, and store it in a cool, dry place when not in use.

What should you do if the TIMER TT120-W Minute Desk Visual Timer stops working?

If the TIME TIMER TT120-W Minute Desk Visual Timer stops working, check and replace the AA battery if necessary, and ensure the battery contacts are properly connected.

Where can the TIME TIMER TT120-W Minute Desk Visual Timer be used?

The TIME TIMER TT120-W Minute Desk Visual Timer can be used in various settings, including classrooms, offices, and homes, to help manage time effectively and increase productivity.


How does the TIME TIMER TT120-W enhance productivity?

The TIME TIMER TT120-W enhances productivity by helping users stay focused on tasks and manage their time effectively.

What power source does the TIME TIMER TT120-W require?

The TIME TIMER TT120-W requires 2 AA batteries to operate, which are not included with the timer.

Video-TIME TIMER TT120-W Minute Desk Visual Timer



Dopoloadıtbissplius TWDEc THIER/up 1 6 2 0 3 / 2 0 / 2

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.