



# TimeMoto TM-616 Time Clock Device Installation Guide

[Home](#) » [TimeMoto](#) » TimeMoto TM-616 Time Clock Device Installation Guide 



## Quick Installation Guide

TM—616 / TM—626 / TM—818 / TM—828 / TM—838

Thank you for choosing TimeMoto. Read this to get started.


### Contents

- [1 What do you need?](#)
- [2 What's in the box](#)
- [3 Connect your device](#)
- [4 Plug in your device](#)
- [5 Setup your device](#)
- [6 Create your account](#)
- [7 Register online](#)
- [8 Mounting your device](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)

## What do you need?

- TimeMoto time clock device
- PC, laptop, tablet, smartphone with Wi-Fi connection
- Main power outlet
- Wi-Fi network name and password or LAN network

## What's in the box




## What's in the box


Unpack the box. During the setup process you must select your preferred software solution.

## Connect your device

### Option 1: WI-FI




### Option 2: LAN



**Option 1:** Wi-Fi for wireless network. Only connect the supplied power adapter to the time clock device.


**Option 2:** LAN for wired network. Connect a LAN network cable and the supplied power adapter to the time clock device.

**Plug in your device**



Plug in the TimeMoto device to the power outlet.

### **Setup your device**




After plug in, the welcome screen of the TimeMoto device shows 'SSID: TimeMoto-.....' followed by a six-digit number.  
The device now creates a temporary network.  
Create a connection between your TimeMoto device and your PC, laptop, tablet or smartphone



Create a connection between your TimeMoto device and your PC, laptop, tablet or smartphone  
Use a PC, laptop, tablet or smartphone to scan for available Wi-Fi networks. Then select the temporary network that starts with 'TimeMoto-.....' followed by a six-digit number.  
**Launch an internet browser**




Launch an internet browser on your connected PC, laptop, tablet or smartphone. Enter the following address in the URL bar: <http://192.168.8.1>. Your PC, laptop, tablet or smartphone will display the TimeMoto setup.  
**Select your language**



Select your language. Click 'Next'.

#### **Software selection**



### Option 1: TimeMoto Cloud Easy Time & Attendance Powered by the Cloud

- Access data from any location
- Connects multiple time clocks
- Clock in and out from mobile devices
- Also works with TimeMoto App
- Paid subscription



### Option 2: TimeMoto PC Plus Software Time & Attendance for single Windows PC use

– Paid licence (30-day trial)

Select the solution you want to use. For more info: [www.TimeMoto.com](http://www.TimeMoto.com)

**Option 1:** TimeMoto Cloud. Suitable for any computer, tablet or smartphone with Windows, Mac OS or Android. TimeMoto Cloud's power, scalability and flexibility, make it the ultimate time and attendance solution for every company.

**Option 2:** TimeMoto PC Plus Software (paid licence). Software for single Windows PC use.

**Select your network connection**






How do you want your TimeMoto device to connect to your network?

**Option 1** – Wi-Fi: Select Wi-Fi and click 'Next'. Go to Step 10.

**Option 2** – LAN: Make sure a network cable is plugged in. Click 'next' to confirm. Click 'next' to approve 'DHCP'. Go to Step 11.


**Enter your Wi-Fi network details**




### Enter your Wi-Fi network details

Select your Wi-Fi network. Enter your password.  
Click 'Next'.

### Confirm your settings




Confirm your settings by clicking 'Next' or click 'Change' to adjust your chosen settings.  
**Finish the setup**




Your TimeMoto device is now successfully configured and will automatically restart. Please wait until you see the 'Register' button turn green. Click 'Register'.

## Create your account




Create your TimeMoto Cloud or PC Plus Software account. You will receive a confirmation e-mail after registration with an activation (download) link.

## Confirmation e-mail



Please follow the steps in the confirmation e-mail to successfully setup your TimeMoto Cloud or PC Plus Software. You can also find links to the most important articles, tutorials and videos to help you get started.


**Register online**



Your TimeMoto device comes with a 2-year warranty. To extend your warranty for 1 additional year, register your product within 30 days from the date of purchase.

Go to: [www.timemoto.com/register](http://www.timemoto.com/register)

## **Mounting your device**



Mounting your device

More info, articles, tutorials & videos

TM1 and PC Plus Software: [support.timemoto.com](https://support.timemoto.com) | TM2: [help.timemoto.com](https://help.timemoto.com)

## 3 year warranty

Register Online.

Your TimeMoto Time Clock comes with a 2-year warranty. To extend your warranty for 1 additional year, register your product within 30 days from the date of purchase. [www.timemoto.com/register](http://www.timemoto.com/register)

## FCC compliance

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimetres between the radiator and your body.

TimeMoto is a registered trademark of TimeMoto Holding B.V. and TimeMoto B.V. © TimeMoto Holding B.V. All rights reserved. TimeMoto B.V. – PO Box 7067 – 2701 AB Zoetermeer – NL. [www.timemoto.com](http://www.timemoto.com) 231





## Documents / Resources

	<p><a href="#">TimeMoto TM-616 Time Clock Device</a> [pdf] Installation Guide TM-616 Time Clock Device, TM-616, Time Clock Device, Clock Device, Device</p>
---	---



## References

-  [TimeMoto](#)
-  [TimeMoto](#)

Manuals+.