



# Timsen Development BR-002 Bluetooth Gramophone Instruction Manual

[Home](#) » [Timsen Development](#) » Timsen Development BR-002 Bluetooth Gramophone Instruction Manual 

## Contents

- [1 Timsen Development BR-002 Bluetooth Gramophone](#)
- [2 Please read the instruction manual carefully before operation.](#)
- [3 Structure Diagram of Classical Multi-function Player](#)
- [4 Function Instruction](#)
- [5 FCC Statement](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

# Timsen


Timsen Development BR-002 Bluetooth Gramophone



**Please read the instruction manual carefully before operation.**

- When this product is idle, please power off.
- Please do not expose this product under the sunshine; the dry and cool environment will be optimal.

## Structure Diagram of Classical Multi-function Player



1. Antique Trumpet
2. Control Button
3. ON/OFF Power button
4. 5V DC Supply Hub
5. External Connection of Signal Input Hub
6. Foot pad
7. Foot pad
8. Bass speaker
9. Vibrating Film
10. tweeter

## Function Instruction

1. Connect the power adopter matched the machine
2. Power ON: press the ON/OFF button which in the back of the machine, the unit would have a beep sound, then will switch to Bluetooth mode.
3. open the Bluetooth of the equipment ( such as cell phone or computer etc ) search for BR-002 and pair
4. After successfully match, the machine sounds the warning tome,then you could play music.
5. Pause and play: shortly press the control button, the music would be paused, press again, the music would play again.
6. the playable music format can be decided according to the format that is supported by your equipment
7. rotate the control button clockwise the volume will increase.

8. rotate the control button anticlockwise the volume will decrease
9. rapidly and press the control button for 2 times the next song will play
10. rapidly and press the control button for 3 times the previous song will play
11. Power off: when you want to power off, please firstly decrease the volume, then press the ON/OFF button.

## FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

## Documents / Resources

	<p><a href="#">Timsen Development BR-002 Bluetooth Gramophone</a> [pdf] Instruction Manual BR-002, BR002, 2A2FDBR-002, 2A2FDBR002, BR-002 Bluetooth Gramophone, Bluetooth Gramophone, Gramophone</p>
--	--