

TINYCAM Monitor PRO for IP Cam User Guide

Home » TINYCAM » TINYCAM Monitor PRO for IP Cam User Guide 🖺

Contents

- 1 TINYCAM Monitor PRO for IP Cam
- 2 Instructions
- 3 Documents / Resources
- 3.1 References
- **4 Related Posts**




TINYCAM Monitor PRO for IP Cam



Instructions

Android Devices

- 1. Download the "TinyCam Pro" app. Scan the QR code to the left, or visit www.minigadgets.com/tcpdroid on your android device.
- 2. Power on your device, then connect to the device's Wi-Fi signal on your phone. Go to your phone's Settings > Connections > Wi-Fi and select the AIS_ signal to join (the below is an example of that signal)



- 3. Once connected, open the TinyCamPro app. Press the + button on the bottom and choose 'Add in LAN'.
- 4. It should say 'Found 1 Devices'. Tap on the long string of numbers underneath this and it will load the camera's information in for you.
 - Press on the 'OK' button. If this does not happen, please go to your phones Settings > Connections Wi-Fi > Advanced and turn off 'Switch to mobile data', and then try again.
- 5. It should now be 'Online'. Tap the gear icon to the bottom right.
- 6. Select the 'Wi-Fi Config' section.

- 7. Choose a wi-fi network to connect the device to. Enter the password at the top of the page and then choose the 'OK' button on the bottom.
 - If your network is still not listed, move closer to the router.
 - If the camera fails to connect, please retry and try moving the device closer to the router it is being paired to.
- 8. The device will have a progress circle and say 'Connecting...'
- 9. Once the circle reaches 100% it will turn into a green check mark and say 'Connection is completed'. Press on 'OK'.
- 10. Your camera is now paired to your router and ready for remote viewing. Tap on the play button icon to enter the live stream.

Scan for instructional videos

• To reset your device, hold the reset button on the back in for 10 seconds and let go



Documents / Resources



TINYCAM Monitor PRO for IP Cam [pdf] User Guide Monitor, Monitor PRO, IP Cam

References

• retcpdroid

Manuals+,