



Home » TKO Strength » TKO Strength 982DB-B Decline Olympic Bench Owner's Manual 📆



TKO Strength 982DB-B Decline Olympic Bench



Contents [hide]

- 1 Safety
- 2 Instructions
- 3 Tools Required
- 4 Exploded Diagram
- 5 Parts List
- 6 Assembly Instruction
- 7 Maintenance Schedule
- 8 General Maintenance Information
- 9 Customer Support
- 10 Documents / Resources
 - 10.1 References

Safety

Read this owner's manual carefully before assembling or using TKO equipment.

WARNING: Serious injury could occur if these safety precautions are not observed

Safety Precautions

- Before beginning any exercise program, consult your personal physician. Evaluate your present fitness level and determine the exercise program that is most appropriate for your particular age and condition.
- If you experience any pain or tightness in your chest, irregular heartbeats, shortness
 of breath, faintness or other unusual discomfort while exercising, stop and consult your
 physician before continuing.
- Make sure that the equipment(s) are set up and operated on a solid level surface.
 DO NOT install or use the equipment on an uneven surface.
- Exercise equipment has moving parts. In the interest of safety, keep others, especially children, at a safe distance while exercising.
- Make sure there are enough room for access and operate the equipment(s) safely.
- Inspect and maintain the equipment(s) regularly.
- Replace the worn or damaged parts/components immediately to ensure safety.

- Use a spotter.
- Back support cushion may drop when knob is pulled. Hold the back support cushion when adjusting it.
- Make sure the pull pin is fully engaged before use.
- Lower the back support cushion to the lowest position when not in use.
- Warm up 5 to 10 minutes before each workout and cool down 5 to 10 minutes afterward. Never hold your breath while exercising.
- Remove all jewelry, including rings, chains and pins before commencing exercise.
- Always wear suitable clothing and footwear during exercise. Do NOT wear loose fitting clothing that could become entangled with the moving parts of your exercise machine.
- Rest adequately between workouts. Muscles tone and develop during these rest periods.
- Most exercise equipment is not recommended for small children. Children should not use the machine unless they are under adult supervision.


Instructions

Before beginning assembly please take the time to read instructions thoroughly. Please use the various lists in this manual to make sure that all parts have been included in your shipment. When ordering, use part number and description from the lists. Use only our replacement part when servicing. Failure to do so will void your warranty and could result in personal injury.


The equipment is designed to provide the smoothest, most effective exercise motion possible. After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call your authorized dealer. Be sure to have your serial number and this manual when calling. When all parts have been accounted for, continue on.

Tools Required

Ratchet Wrench and Socket



• Adjustable Wrench



• Rubber Mallet



• Hex Key Wrench Set




Exploded Diagram

NOTE: SOME OF THESE PARTS MAY COME PRE-INSTALLED


Item No.	Description	QTY
1	Seat Frame	1
2	Adjustable Frame	1
3	Left Frame	1
4	Right Frame	1
5	Cross Connection Frame	1
6	Weight Plate Bar	4

7	Fixed Plate	2
8	Foam Frame	1
9	Leg Pad	1
10	Back Pad	1
11	Foam	2
12	Pop Pin	1
13	Plug 50*100	4
14	Foot Cover	5
15	Rubber Bumper	4
16	Plug φ48	4
17	Plastic Tube Guide	2
18	Plastic Spacer	4
19	Small Cap	2
20	Hook Protector	4
21	Top Hook Protector	2
22	Bottom Hook Protector	2
23	Straight Hook Protector	2
24	Flat Washer φ13*φ24*1.5	4
25	Hex Head Bolt M12*25	4
26	Socket Head Cap Screw M10*25	2
27	Flat Head Cap Screw M10*30	10

28	Hex Head Bolt M10*80	10
29	Hex Head Bolt M10*30	8
30	Flat Washer φ11*φ20*2	26
31	Flat Head Cap Screw M10*30	10
32	Nylon Lock Nut M10	8
33	Socket Head Cap Screw M8*30	1
34	Socket Set Screw M8*10	1
35	Button Head Cap Screw M6*12	2
36	Hex Nut M6	2



Parts List



Assembly Instruction

Assembly of the equipment takes professional installers about 2 hours. If this is the first time you have assembled this type of equipment, plan to spend more time. It is strongly recommended to assemble the equipment by professional installers. You may find it quicker, safer, easier to assemble this equipment with the help of a friend, as some of components may be large, heavy or awkward to handle alone. It is important that you assemble your product in a clean, clear, uncluttered area. This will enable you to move around the product while you are fitting components and reduce the possibility of injury

during assembly.



As with any assembled part, proper alignment and adjustment is critical. While tightening the fasteners, be sure to leave room for adjustments. Do not fully tighten the fasteners until instructed to do so. Be careful to assemble the components in the sequence presented in this guide.

Maintenance Schedule

ROUTIN	COMMERC IAL MAINT ENANCE	HOME MAI NTENANC E	LATEST DATE ENTRY			
Inspect; Links, P ull Pins, Snap Lo cks, Swi vels, Wei ght Stac k Pins	DAILY	WEEKLY				
Clean; Upholste ry	DAILY	WEEKLY				
Inspect; Cables o r Beits a nd their t ension.	DAILY	WEEKLY				

Inspect; Accessor y Bars, a nd Handl es	WEEKLY	3 MONTHS				
Inspect; All Decal s	WEEKLY	3 MONTHS				
Inspect; All Nuts and Bolt s, Tighte n if need ed	WEEKLY	3 MONTHS				
Inspect; Anti-Skid Surface	WEEKLY	3 MONTHS				
Clean & Lubricate ; Guide R ods with a Tefion (PTFE) b ased lubricant (Superlu be)	MONTHLY	3 MONTHS				

Lubricate; Seat Sle eves, Tur cite Bush ings, Lin ear Beari ng	MONTHLY	3 MONTHS				
Clean an d Wax; All Gloss y Finishe s	6 MONTHS	YEARLY				
Repack with Gre ase; Linear B earings	6 MONTHS	YEARLY				
Replace; Cables, Belts an d Conne cting Par ts	YEARLY	3 YEARS				

Your equipment comes with a commercial maintenance decal. For personal, in home use, please follow the home maintenance schedule listed above.

General Maintenance Information

Links, Pull-Pins, Snap Hooks, Swivels, Weight Stack Pins:

- Check all pieces for signs of visible wear or damage.
- Check springs in snap hooks and pull-pins for proper tension and alignment.
- If the spring sticks or has lost its rigidity, replace it immediately.

Upholstery:

- To ensure prolonged upholstery life and proper hygiene, all upholstered pads should be wiped down with a damp cloth after every workout.
- Periodically take the time to use a mild soap or an approved vinyl upholstery cleaner to deter the onset of cracking or drying. Avoid using any abrasive cleaners or cleaners not intended for use on vinyl.
- Replace ripped or warn upholstery immediately.
- Keep sharp or pointed objects clear of all upholstery.

Decals:

 Inspect and familiarize yourself with any safety warnings or other user information posted on each decal.

Nuts and Bolts:

- Inspect all nuts and bolts for any loosening and tighten if needed.
- Go through a re-tightening sequence periodically to ensure that all hardware is tensioned proper.

Anti-Skid Surfaces:

 These surfaces are designed to supply secure footing and need to be replaced if they appear worn or become slippery.

Belts and Cables:

- We uses only high quality belt, and mil-spec cables.
- Visually inspect the belts and cables for fraying, cracking, peeling or discoloration.
- While the machine is not in use, carefully run your fingers along the belt or cable to

feel for thinning or bulging areas.

Replace belts and cables immediately at the first signs of damage or wear. Do not use

equipment until belts or cables have been replaced.

Belt and Cable Tension:

• Referring to the Owners Manual, when belts or cables are used check all bolts

attachments to be sure they are properly attached.

Check slack in cables and re-adjust cable tension if needed.

Seat Sleeves, Guide Rods:

• Wipe down adjusting tubes with a dust free rag before applying lubricant.

• Lubricate seat sleeves and Guide Rods with a Silicon or Teflon based lubricant spray.

Linear Bearings:

Referring to the Owners Manual carefully disassemble the bearing from its housing

and place a finger full of light grease (lithium, super lube, etc.) into the inside of the

bearing. Using your finger, press the grease into the ball-bearings and their tracks.

repeat until the ball-bearing tracks are full of grease. Insert the shaft back into the

bearing and wipe off excess grease.

PLEASE KEEP THIS FOR YOUR RECORDS

Customer Support

Customer Service: <u>866-856-3488</u> or <u>713-895-9270</u>

email: sales@tkostrength.com

Hours: Monday-Friday 8:30am to 4:30pm CT

© Copyright 2016, TKO Strength & Performance Inc. All rights reserved.

TKO Strength & Performance Inc. 6387 Windfern Road, Houston, TX 77040

P: 713-895-9270 FAX:+713-934-8495

www.tkostrength.com



Documents / Resources



TKO Strength 982DB-B Decline Olympic Bench [pdf] Owner's Manual 982DB-B Decline Olympic Bench, 982DB-B, Decline Olympic Bench, Olympic Bench, Bench

References

- User Manual
- TKO

Strength

982DB-B, 982DB-B Decline Olympic Bench, Bench, Decline Olympic Bench, Olympic Bench, TKO Strength

Leave a comment

Your email address will not be published. Required fields are marked*						
Comment *						
Name						
Email						

Website	

 $\ \square$ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.