



# TMKB GK61 RGB Wireless Mechanical Gaming Keyboard User Manual

[Home](#) » [TMKB](#) » TMKB GK61 RGB Wireless Mechanical Gaming Keyboard User Manual 

## Contents

- [1 TMKB GK61 RGB Wireless Mechanical Gaming Keyboard](#)
- [2 Wireless mode](#)
- [3 FUNCTION](#)
- [4 STATUS](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



**TMKB GK61 RGB Wireless Mechanical Gaming Keyboard**



## Wireless mode

### Wired/ Bluetooth / 2.4G mode switching

- **FN + space** keyboard flashes white light three times to switch wired mode. When FN is pressed, the white light in the space indicates that it is currently in wired mode
- **FN + space** keyboard flashes blue light three times to switch wireless mode. When FN is pressed, the blue light in the space indicates that it is currently in Bluetooth mode
- **FN + space** keyboard flashes green three times to switch 2.4G mode. When FN is pressed, the green light of the space indicates that it is currently in 2.4G mode

1. The three modes are switched through FN + spacebar polling. The current status can be queried by pressing FN to view the light color of the spacebar.
2. After the link is successful, short press FN + Z, X and C to connect the paired host (switching device)
3. In Bluetooth mode, press FN to display the channel
4. The back on-off is only a power switch. For example, the current keyboard is in wired mode, so only wired functions can be used, and Bluetooth / 2.4G functions cannot be used
5. **FN + y** = 2.4G pairing link (in the 2.4G mode, you need to enter the pairing mode first and then insert the

receiver. Even after reset, you need to pair first and then insert the receiver)

## FUNCTION

Fn+ 1 = F1	Fn + 2 = F2	Fn+ 3 = F3	Fn + 4 = F4
Fn+ 5 = F5	Fn + 6 = F6	Fn+ 7 = F7	FN + 8 = F8
Fn+ 9 = F9	Fn + 0 = F10	Fn+ (-_) = F11	Fn + (=+) = F12
FN + Shift + Esc = ~	FN + Esc = `	FN + U = Print Screen	Fn+ I = Scroll Lock
FN + 0 = Pause	Fn+ J = Insert	Fn+ K = Home	Fn+ L = PageUp
Fn+ M = Delete	Fn + <, = End	Fn + >, = PageDown	
Fn+ /? = ↑	Fn+ ALT-R = ←	Fn+ Ctrl-R = →	Fn+ menu = ↓

- **FN + Win** = Win key lock/ unlock
- (Win Key turn on red light when its lock)
- **FN + I** = Switches the keyboard built-in lighting effect
- **FN + ]** = Switches the keyboard lighting effect to solid color FN+ [{ = Increase the brightness of the light effect
- (The red light of [{key flashing 3 times when the light is set to the brightest) FN+ P = Decrease the brightness of the light effect
- (The red light of P key flashing 3 times when the light is set to the darkest)
- **FN + “”** = Increase the speed of the light effect
- (The red light of” key flashing 3 times when the light is set to the fastest)
- **FN + ; :** = Decrease the speed of the light effect
- (The red light of;: key flashing 3 times when the light is set to the lowest speed )
- **FN + V** = Switch to MAC mode
- (Keyboard flashing red backlight three times)
- **FN+ B** = Switch to WIN mode
- (Keyboard flashing red backlight three times)
- **FN+ N** = Switch the NKRO
- (N-Key Rollover, also known as anti-ghost) and 6KRO mode (NKRO mode = The “N” key show RED light when you pressing the FN key)
- **FN+ Tab** = Press “FN + Tab” at least 3 seconds Reset to the factory default
- **FN + Backspace** = Turn up / off the back light of keyboard
- **FN + Enter** = Lock / unlock FN
- (FN key show the red light after locked, Press again to unlock )
- **FN + Q** = Profile 1
- **FN + W** = Profile 2
- **FN + E** = Profile 3
- **FN + R** = Profile 4
- **FN + T** = Switch back to standard layer
- **FN + H** = Volume Up
- **FN + A** = Pause / Play FN + S = Previous song FN + D = Next song FN + F = Mute switch FN + G = Volume Down
- **Ps:** For example, when the keyboard is in profile 1, press the FN key, the Q key lights

## STATUS


The status of the keyboard can be displayed when pressing the Fn key In Wired Mode, press FN + R-ALT button to display the power status  
(release to restore the original light effect)

- **Power Status** R-ALT Key
- **Fully Charged** Light up Green
- **In Charging** Light up Blue

**In Bluetooth Mode, press FN + R-ALT button to display the power status**

- (release to restore the original light effect)
- Power Status R-ALT Key Power Status R-ALT Key
- 95%-100% Light up Green 20%-50% Light up Yellow
- 50%-95% Light up Blue Less than 20% Light up Red
- Please feel free to contact us if you meet any questions we using our products. [customer@tmkb.com](mailto:customer@tmkb.com)
- [www.tmkb.com](http://www.tmkb.com)
- Made in China

## Documents / Resources

	<a href="#">TMKB GK61 RGB Wireless Mechanical Gaming Keyboard</a> [pdf] User Manual GK61, GK61 RGB Wireless Mechanical Gaming Keyboard, RGB Wireless Mechanical Gaming Keyboard, Wireless Mechanical Gaming Keyboard, Mechanical Gaming Keyboard, Gaming Keyboard, Keyboard
---	--