


TOGUARD AP35 Security Camera User Guide

Home » TOGUARD » TOGUARD AP35 Security Camera User Guide 🖫

TOGUARD

AP35
Toguard Battery Powered
Smart Camera Quick Guide



Contact <u>US:support@toguard.cc</u>

The battery-powered IP camera works with app: adorcam Search "Adorcam" in App store or google play store, or scan the above QR Code to download and install on a smartphone.



If you want to get a more detailed operation manual, please scan the QR code below to get a user manual in PDF. Or you can go to our official website: https://www.toguard.cc and get the User Manual in the Download section.



https://www.toguard.cc/pages/toguard-ap30-user-manual


Contents

- 1 Packing list
- **2 Product Details**
- 3 Install Adorcam APP and register an account
- 4 Add Camera to APP
- **5 Insert Micro SD Card**
- **6 Share Camera to Family**
- 7 Online Help
- **8 LED Status Description**
- 9 Trouble Shooting
- 10 Documents / Resources
- 11 Related Posts

Packing list

Ix camera, Ix wall mount, Ix screws Ix power cable, Ix Quick User Guide

Product Details



Install Adorcam APP and register an account

Add Camera to APP

- 4.1 Insert Micro SD card (No Card, No videos)
- 4.2 Power on the camera (Press power key over 5 seconds till the indicator flashes slowly in red)
- 4.3 Setup Wi-Fi
- 4.3.1 Connect your phone with 2.4Ghz WiFi (5Ghz WiFi is not supported.)
- 4.3.2 click "add camera" and select the 2.4Ghz WiFi, input correct password, and click next to generate one QR code.
- 4.3.1 Take the camera to scan the OR code.
- 4.3.4 After hearing one tone and clicking next to connect.

NOTE: If failed to connect, please RESET: Short press the power key twice, like double click the mouse, and you will hear one tone and the LED turns to red and flashing slowly, that is meaning awaiting for WiFi connection.

Insert Micro SD Card

If no card, no recorded videos, please insert a good brand Micro SD card, such as Sandisk/Kingston 4-128GB, recommended 32GB. If the SD card not is recognized, please kindly format it in-app or take out the sd card to

format on PC in NTFS format and plugin again.

Share Camera to Family

Operation: Upper left menu-Share One camera is allowed by one phone connected. One account is allowed to connect with one phone. Once the same account login by 2nd phone, the 1st phone will auto log out.

NOTE: New account should be registered in adorcam app and select the same region/country with your account. If you have sent one invitation, but the invitation had not been accepted, you cannot send 2nd invitation. You can delete the invitation, and send a new invitation again.

Online Help

Any support needed, you can contact us online.



LED Status Description

- 1. No light: Sleep/shutdown
- 2. Red light solid on In charging
- 3. Red light flashes slowly (once every second): Awaiting for WiFi connection
- 4. Fast red light (multiple times a second): WiFi connecting
- 5. Blue light solid on Alarm recording
- 6. Blue light flashes slowly (once every two seconds): Camera in live view status
- 7. Blue light flashes quickly (multiple times a second): Upgrading status

Trouble Shooting

- 1. Unable to connect:
 - 1)Check your WiFi name and password
 - 2) Ensure your WiFi is 2.4G HZ, not the 5G HZ WiFi
 - 3) Ensure your camera and phone close to router
- 2. RESET:
 - 1)Press and power button twice and Hear one tone.
 - 2) Indicator turns to flash slowly in red.
- Change to a new Network

Reset and re-connect camera.

- 4. No Alarm Push Please enable notification permissions in adorcam app.
- 5. No Alarm Push: Please insert Micro SD card.

Documents / Resources



TOGUARD AP35 Security Camera [pdf] User Guide AP35 Security Camera, AP35, Security Camera

Manuals+,