



TOOLOTS C11-10C Multi Device 10 Port Charging Station User Manual

[Home](#) » [TOOLOTS](#) » TOOLOTS C11-10C Multi Device 10 Port Charging Station User Manual 

Contents

- [1 TOOLOTS C11-10C Multi Device 10 Port Charging Station](#)
- [2 Introduction](#)
- [3 Specification](#)
- [4 Charge](#)
- [5 Cleaning](#)
- [6 Storage](#)
- [7 Move and Transportation](#)
- [8 Environment](#)
- [9 Documents / Resources](#)



TOOLOTS C11-10C Multi Device 10 Port Charging Station



Introduction

Please read this User Manual, as it contains information about the wonderful features of this Charging Trolley as well as some tips to make it more enjoyable.

Important

Read this user manual carefully before you use the appliance. Save it for future reference.

Danger


Make sure the AC power section {plug/socket} does not get wet.

Specification


Model	C11-10C
Input	100~120V-50/60Hz 6.8A Max
Output/Port	5V-3A 9V-2A 12V-1.5A Max
Charging Standard Complied with	PD3.0, QC4/QC4+, Apple2.4A(Divider1/2/3), Samsung(D+/D- 1.2V), BC 1.2
Charging Ability	10pcs USB-C Device
LED Indicators	Green: Fully Charged/No Load
	Red: Charging
Slot Size	10.63×8.27×1.02"
Case Size ^e	19.29×14.17×10.43"

Charge



1. Put the charging trolley on a flat surface near an AC socket. Ensure the ventilation system not be covered.




2. Open the charging trolley.




3. insert the power cord plug into the external connector of the charging trolley, press down the silver slider, and with it pointing upwards. Then turn the plug to the right until the slider clicks into place and connect the other end with the AC socket.



4. Press “I” to power the charging trolley.



5. Put tablets into the inner compartments of the trolley, connect USB ports and tablets with USB cables, then tablets are charged. Tips: The USB cables can be easily managed by tying them up into small loops.



Cleaning

- Always unplug the charging trolley before you clean it.
- Clean the surface with a dry damp cloth.

Storage

Store charging trolley in the conditions of temperature -13 ~ 122 and relative humidity 20-90% RH non-condensing.

Move and Transportation


1. Press “O” to turn off the power
2. Unplug the USB cables.
3. Unplug the AC power cord.

- 4. Make sure all the accessories are stored well in the correct position.
- 5. Close the charging trolley and lock the latches.

Environment

Do not throw away the appliance as normal household waste, but hand them in at an official collection point for recycling. By doing this, you help to preserve the environment.

Documents / Resources

	<p>TOOLOTS C11-10C Multi Device 10 Port Charging Station [pdf] User Manual C11-10C-2, C11-10C Multi Device 10 Port Charging Station, C11-10C, C11-10C 10 Port Charging Station, Multi Device 10 Port Charging Station, Device 10 Port Charging Station, 10 Port Charging Station, Charging Station</p>
---	---