



[Home](#) » [TOOLPORT](#) » **TOOLPORT Outlander Lager Prof Installation Guide** 

Contents [[hide](#)]

- [1 TOOLPORT Outlander Lager Prof](#)
- [2 Product Usage Instructions](#)
- [3 WHAT'S IN THE BOX](#)
- [4 Parts Description](#)
- [5 Hardware List](#)
- [6 Assmbley Instruction](#)
- [7 MORE INFORMATION](#)
- [8 Frequently Asked Questions](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

TOOLPORT

TOOLPORT Outlander Lager Prof



Product Specifications

- **Brand:** OUTLANDER
- **Available Sizes:** 4m x 6m, 4m x 8m, 4m x 10m
- **Material:** Various materials
- **Item Numbers:** 32648, 32649, 31597, 35355, 35126, 35127, 35112, 35113, 30359, 31137

Product Usage Instructions

Assembly

1. Identify the appropriate size of the OUTLANDER product based on your requirements.
2. Refer to the item number provided to ensure you have the correct product.
3. Set up the OUTLANDER product in a clear outdoor area free from obstructions.
4. Follow the specific assembly instructions provided in the manual for your chosen size.


Installation

1. Secure the OUTLANDER product firmly to the ground using appropriate fasteners.
2. Ensure all corners and edges are properly anchored to prevent movement in windy conditions.
3. Double-check the stability of the structure before use.
















Maintenance











1. Regularly inspect the product for any signs of wear and tear.
2. Clean the OUTLANDER product with mild soap and water when necessary.
3. Store the product in a dry place when not in use to prolong its lifespan.

WHAT'S IN THE BOX














Parts Description

Item no.		6 m	8 m	10 m
32648	 Ø50 mm ← 1483 mm →	8	10	12
32649	 Ø50 mm ← 632 mm →	8	10	12
31597	 Ø38 mm ← 1895 mm →	4	4	4
35355	 Ø38 mm ← 1920 mm →	11	16	21
35126	 Ø50 mm ← 1507 mm →	8	10	12
35127	 Ø50 mm ← 1483 mm →	8	10	12
35112	 Ø38 mm ← 1920 mm →	4	4	4
35113	 Ø25mm ← 1408mm →	8	8	8
30359	 Ø25mm ← 1658 mm →	4	5	6
31137		6	6	6
31138		6	9	12
35120		4	4	4
35121		4	6	8
35122		2	2	2
30993	 Ø25mm ← 1880mm →	6	8	10





Item no.		6 m	8 m	10 m
31717		56	56	56
30047	 ← 160 mm →	34	38	42
31159	 ← 600 mm →	8	10	12
30409		18	24	30
30410		4	4	4
30081	 ← 935 mm →	12	16	20
30080		6	8	10
33096		8	10	12
		-	1	1
		-	2	2

Hardware List


Item no.			6 m	8 m	10 m
33413	M6 30 mm		8	10	12
33414	M6 45 mm		4	4	4
33415	M6 55 mm		8	8	8
33416	M6		8	10	12
33417	M8 50 mm		42	52	62
33418	M8 70 mm		56	90	84
30535	M8		94	118	142
30407	M6		12	12	12
30852	M8		2	2	4
33412	M6		2	2	2
32361	M8		4	4	4

Assmbley Instruction


1




2



33096






M8 33417




M8 33418



M8 30535



32648




31137/
31138

33096

32648

3



M6 33413



M6 33416



30081



30080

Ø25 mm





← 1652 mm →





30359






33096






4







5






6






7







8







9





10






11






13





MORE INFORMATION




- **Telefon +4904060872717**
- **Fax +4904060872737**
- www.toolport.de



Frequently Asked Questions

- **Q: How do I choose the right size of the OUTLANDER product?**
 - **A:** Determine your space requirements and select a size that fits comfortably within that space.
- **Q: Can I leave the OUTLANDER product assembled outdoors for an extended period?**
 - **A:** It is recommended to disassemble and store the product when not in use to prevent damage from weather conditions.
- **Q: What should I do if I notice a tear or damage on the OUTLANDER product?**
 - **A:** Repair any tears promptly using a patch kit provided by the manufacturer to avoid further damage.

Documents / Resources

	<p>TOOLPORT Outlander Lager Prof [pdf] Installation Guide</p> <p>32648, 32649, 31597, 35355, 35126, 35127, 35112, 35113, 30359, 31137 , Outlander Lager Prof, Lager Prof, Prof</p>
---	--

References

- [User Manual](#)

TOOLPORT

30359, 31137, 31597, 32648, 32649, 35112, 35113, 35126, 35127, 35355, Lager Prof, Outlander Lager Prof, Prof, TOOLPORT

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.