



# TORO 51810T Flex-Force Power System User Manual

[Home](#) » [Toro](#) » TORO 51810T Flex-Force Power System User Manual 

## Contents


- [1 TORO 51810T Flex-Force Power System](#)
- [2 Power Head Assembly](#)
- [3 Attachments and Accessories](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)



**TORO 51810T Flex-Force Power System**



## Power Head Assembly




Ref.	Part Number	Qty.	Description
1		1	Power Head ●
2	145-4866	1	Handle
3	145-4865	1	Collar-Harness
4	145-4867	1	Screw-Wing
5	145-4868	1	Stand

## Attachments and Accessories

For 51810T Flex-Force Power System 60V MAX Power Head

Product Name	Model/Part
60V Battery Charger 2 AMP .....	88602
60V Rapid Battery Charger 5.4 AMP .....	88605
60V Battery Charger 1 AMP .....	88610
60V 2.0 AH Battery .....	88620
60V LI-ION Battery 2.5 AH.....	88625
60V LI-ION, Battery 4.0 AH .....	88640
60V LI-ION Battery 5.0 AH.....	88650
60V LI-ION Battery 6.0 AH.....	88660
60V LI-ION Battery 7.5 AH.....	88675
Edger Attachment for 60V Trimmer .....	88710
Hedge Trimmer Attachment for 60V Trimmer.....	88713
Pole Saw Attachment for 60V Trimmer .....	88714
Cultivator Attachment for 60V Trimmer .....	88715
14in and 16in Trimmer Attachment .....	88716

Documents / Resources

	<p><a href="#">TORO 51810T Flex-Force Power System</a> [pdf] User Manual</p> <p>51810T Flex-Force Power System, 51810T, Flex-Force Power System, Power System</p>
--	---

References