

TOSIMA W2 Window Cleaning Robot Black



TOSIMA W2 Window Cleaning Robot Black User Guide

[Home](#) » [Tosima](#) » TOSIMA W2 Window Cleaning Robot Black User Guide 

Contents

- [1 TOSIMA W2 Window Cleaning Robot Black](#)
- [2 Overview](#)
- [3 INSTALLATION INSTRUCTIONS](#)
- [4 PATH PLANNING](#)
- [5 REMOTE CONTROL](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)




TOSIMA W2 Window Cleaning Robot Black



W2 Quickly Start Guide


Overview

1. ON/OFF/Pause button
2. Indicator light
3. Air outlet
4. Mop holder
5. Cable
6. Upgrade port (for factory use only)
7. Error indicator light (green/red)
8. Safety cable mounting hole




INSTALLATION INSTRUCTIONS

1. Ensure the knob of the safety cable




2. Installation of Mops is fully tightened to the frame.



1. Please make sure the Mop Holder is installed in proper position before use.




2. Cover each mop holder with a mop.
3. Insert the window cleaner power cord into the end of the adapter and tighten them connect the two ends of the ac wire to the adapter and the socket respectively.




PATH PLANNING

Long press the Power / Start button to turn the robot on, and then short press the button to start it, and the robot will automatically move upward, then move right. At last, it will reach the top right corner of the glass. Then starts to clean from top to bottom in an "S" shape. After clean, the robot will stop at the lower-left or right corner according to the glass shape.



REMOTE CONTROL



Notes:

1. Press the start button to turn on the device in automatic mode.
2. Press the "Pause/continue" button before the automatic mode has been switched to manual mode. automatic mode has been switched to manual mode.
3. Press the "Pause/continue" button before the manual mode has been switched to automatic mode, then select the "x1 or x2" button.

To prevent misuse by children, please press the pause button between commands via remote controller. Otherwise, the controller commands button is invalid.

Manufacturer:

Tosima manufacturing(shenzhen) Co., Ltd.

Address: Room 213, Building A2, Fuhai Information Port, Fuhai Street, Baoan District, Shenzhen City, GD, China

www.tosima.cn

E-mail: cs@tosima.cn



[TOSIMA W2 Window Cleaning Robot Black](#) [pdf] User Guide
W2 Window Cleaning Robot Black, W2, Window Cleaning Robot Black, Cleaning Robot Black, Robot Black

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.