

# A3 Change the WIFI password setting

## Contents

- [1 A3 Change the WIFI password setting](#)
- [2 DOWNLOAD](#)
- [3 Related Posts](#)

## A3 Change the WIFI password setting

It is suitable for: **A3**

**Application introduction:** Solution about how to change the wireless name and password on the TOTOLINK products

### STEP-1:

Connect your computer to the router by cable, enter <http://192.168.0.1>

5bd677e9af646.png

**Note:**The default access address varies depending on the actual situation. Please find it on the bottom label of the product.

### STEP-2:

User Name and Password are required, by default both are admin in lowercase letter. Meanwhile you should fill in the verification code .then Click Login.

5bd677f37417c.png

### STEP-3:

Then click the **Advance setup** bottom

5bd677fe7cdb8.png

### STEP-4:

Please go to **Wireless** page, and check which you have selected. then Click 2.4GHz Basic network.

Select **WPAPSK/WPA2PSK+TKIP/AES**, then Input your own **Wireless Network Name** and **Password**, then Click **Apply**.

5bd67b17aa328.png

5bd67b1dcd741.png

#### STEP-5:

Please go to **Wireless** page, and check which you have selected.then Click 5GHz Basic network.

Select **WPAPSK/WPA2PSK+TKIP/AES**, then Input your own **Wireless Network Name** and **Password**, then Click Apply.

5bd67b559c16a.png

5bd67c17e0437.png

---

## DOWNLOAD

A3 Change the WIFI password setting – [[Download PDF](#)]

---