Home » Support » A3 repeater settings

A3 repeater settings

Contents

- 1 A3 repeater settings
- 2 Diagram
- 3 Preparation
- 4 Set up steps
- **5 DOWNLOAD**
- **6 Related Posts**

A3 repeater settings

It is suitable for: A3

Diagram

5bd6ca926aeb5.png

Preparation

- Before configuration, make sure that both A Router and B Router are powered on.
- make sure you know the SSID and password for A router
- Connect your computer to the same network of router A and B.
- move the B router closer to the A router to find the B routing signals better for fast repeater.
- Set both Router A and B should to the same band 2.4G or 5G.

Set up steps

STEP-1: B-Router Wireless Setup

You need to enter the settings page of the router B, then follow the steps illustrated.

In the navigation bar, select Basic Setup->Wireless Setup-> Select 2.4GHz Basic network

Setting Network SSID, channel, Auth, password

Click the **Apply** button

5bd6cb8a5375e.png
STEP-2: B-Router repeater setting
* enter the settings page of the router B, then follow the steps illustrated.
In the navigation bar, select Advanced Setup->Wireless->Wireless Multibridge
For Wireless Multibrige, select 2.4GHz. If you want to use 5GHz for Repeater, choose 5GHz.
In Mode list, select Use Wireless Bridge.
Click the Ap Scan button .
Click AP you need repeater, check SSID
Enter the password for router A (You can check the box next to check the password you entered)
Click the Apply button, Wait for the configuration to finish.
5bd6cb9c71871.png
Note: If repeater success,but you need to replace the network for repeater,there will be prompted the following figure,click yes.
5bd6cbdf09ccf.png
STEP-3: B Router position display
Move the Router B to a different location for a best Wi-Fi access.
5bd6cbf5c5a24.png
DOWNLOAD
A3 repeater settings – [Download PDF]

Repeat the steps 3 through 5 to complete the 5GHz Wi-Fi configuration

Manuals+,