Home » Support » A950RG Repeater Settings 🖫

A950RG Repeater Settings

Contents


- 1 A950RG Repeater
- **Settings**
- 2 Diagram
- 3 Set up steps
- 3.1 DOWNLOAD
- **4 Related Posts**

A950RG Repeater Settings

It is suitable for: A800R, A810R, A3100R, T10, A950RG, A3000RU

Application introduction: Repeater Mode, you can extend the superior Wi-Fi signal by Repeater setting function under the Wireless column to increase the coverage of the wireless signal.

Diagram



Preparation


- Before configuration, make sure that both A Router and B Router are powered on.
- make sure you know the SSID and password for A router
- 2.4G and 5G, you can only choose one for Repeater
- move the B router closer to the A router to find the B routing signals better for fast repeater.

Set up steps

STEP-1 B-Router Wireless Setup

You need to enter the settings page of the router B, then follow the steps illustrated.

① Set 2.4G network -> ② Set 5G network -> ③ Click the Apply button




STEP-2 B-Router Repeater Setup

Enter the Advanced Setup page of the router B, then follow the steps illustrated.

- ① Click Operation Mode> ② Select Repeater Mode-> ③ Click Next button
- 4 In next page, you should click Scan 2.4G or Scan 5G
- ⑤ Choose the A-Router SSID you need to make the Repeater

Note: This article set to A router as an example

- © Enter the **password** for the Repeater router
- Olick connect



STEP-3: B Router Position Display

Move the Router B to a different location for a best Wi-Fi access.



DOWNLOAD

A950RG Repeater Settings – [Download PDF]

Manuals+,