

How do I log into the Web-based Interface of Wireless AP


Contents

- [1 How do I log into the Web-based Interface of Wireless AP?](#)
- [2 DOWNLOAD](#)
- [3 Related Posts](#)


How do I log into the Web-based Interface of Wireless AP?

It is suitable for **iPuppy, iPuppy3**


When you connect your PC to the AP wirelessly, please turn the AP/Router switch to the Router side.

5bd81b76ce308.png

1. Type in 192.168.1.1 in the address field of Web Browser and then press Enter key.


5bd81b7e878ac.png

2. It will show up the following page that requires you to enter valid User Name and Password:

5bd81b8488f63.png

Enter **admin** for User Name and Password, both in lower case letters. Then click **Log In** button or press **Enter** key.

3. Now you have logged into the web interface of the router. On the left, it is a menu bar. The right part shows the parameter settings requiring you to setup.

5bd81b8c1802f.png

DOWNLOAD

How do I log into the Web-based Interface of Wireless AP -[[Download PDF](#)]

Manuals+.