Home » Support » How to select AP/Router mode on travel AP?

Н	low	to	selec	t AP	/Rou	ter n	node	on	travel	AP	?
---	-----	----	-------	------	------	-------	------	----	--------	----	---

Contents								
1 How to select AP/Router mode on travel								
AP? 2 DOWNLOAD								
3 Related Posts								
How to select AP/Router mode on travel AP?								
It is suitable for: iPuppy,iPuppy3.								
We take iPuppy for example								
STEP-1:								
here is a press-button on your router's interface, when Router mode.	n the button is on the left, it's AP mode, on the right, it's							
5bd7befe017a6.png								
STEP-2:								
Log in the router to check the status								
2-1. If you turn the button to the Router side, you shouther router by entering http://192.168.1.1 into the address.	uld connect your computer to the router wirelessly, then login ess bar of your browser.							
5bd7bf05372b1.png								
Then will be a table, please login to the Web Setup in	terface (the default user name and password is admin).							
5bd7bf0b48469.png								
2-2. Select System Status, You will see the table belo	w, and the running mode is Router mode.							
5bd7bf150a582.png								
If you want to switch the router to AP mode, you just r	need to put the button on the surface to AP side, and if you							

want to check the status, please connect it to your PC by cable and other steps is the same as we mention earlier.

DOWNLOAD

How to select AP/Router mode on travel AP -[<u>Download PDF</u>]								

Manuals+,