

How to setup Multi-SSID for the router

Contents

- [1 How to setup Multi-SSID for the router](#)
- [2 DOWNLOAD](#)
- [3 Related Posts](#)

How to setup Multi-SSID for the router


It is suitable for : **N150RA, N300R Plus, N300RA, N300RB, N300RG, N301RA, N302R Plus, N303RB, N303RBU, N303RT Plus, N500RD, N500RDG, N505RDU, N600RD, A1004, A2004NS, A5004NS, A6004NS**

Application introduction:


Multi-SSID allows users to create network name with different priority for clients or friends accordingly. It is good for access control and your data privacy.


STEP-1:

1-1. Connect your computer to the router by cable or wireless, then login the router by entering `http://192.168.1.1` into the address bar of your browser.




Note: The default IP address of TOTOLINK router is 192.168.1.1, the default Subnet Mask is 255.255.255.0. If you can't log in, Please restore factory settings.

1-2. Please click Setup Tool icon  to enter the router's setting interface.




1-3. Please login to the Web Setup interface (the default user name and password is admin).



STEP-2:

2-1. Click Advanced Setup->Wireless->Multiple BSS on the navigation bar on the left.



STEP-3:

Fill in the information about SSID in the blank, and then click Add button to apply modification.

–**SSID:** network name

–**SSID Broadcast:** Select hidden SSID

–**Access Policy:**

a. Allow all: allow users share files or other motion by external network and LAN.

b. Only for Internet: Only allow users hare files or other motion by external network.

–**Encryption** Set encryption key for the wireless network.

5bcd734775c1e.png

STEP-4:

After adding other SSIDs you can see the information in the Wireless Network Information bar.

5bcd734e6d2a9.png

DOWNLOAD

How to setup Multi-SSID for the router – [[Download PDF](#)]
