

# How to update the firmware of the router

## Contents

- [1 How to update the firmware of the router](#)
- [2 DOWNLOAD](#)
- [3 Related Posts](#)

## How to update the firmware of the router

It is suitable for: **N150RA, N300R Plus, N300RA, N300RB, N300RG, N301RA, N302R Plus, N303RB, N303RBU, N303RT Plus, N500RD, N500RDG, N505RDU, N600RD, A1004, A2004NS, A5004NS, A6004NS**

**Application introduction:** New version of firmware will be released to improve the various efficiency or to fix some bugs. Following the steps show below so as to realize upgrading.

### STEP-1: Connect your computer to the router

1-1. Connect your computer to the router by cable or wireless, then login the router by entering http://192.168.1.1 into the address bar of your browser.

5bcfe3c2bc299.png

Note: The default IP address of TOTOLINK router is 192.168.1.1, the default Subnet Mask is 255.255.255.0. If you can't log in, Please restore factory settings.



1-2. Please click **Setup Tool** icon to enter the router's setting interface.


5bcfe3cf6bc7b.png

1-3. Please login to the Web Setup interface (the default user name and password is **admin**).

5bcfe422b1902.png

### STEP-2:

Click **Advanced Setup->System->Firmware Upgrade** on the navigation bar on the left.



### STEP-3:

Click Choose File button to select the firmware version and then click Upgrade button. After the router reboots, upgrade is finished.

5bcfe42fc0f30.png

[ Notice ]

DO NOT power off the device or close the browser window during the upload because it may crash the system.

---

### DOWNLOAD

How to update the firmware of the router – [ [Download PDF](#) ]

---