Home » Support » How to use wireless schedule

How to use wireless schedule

Contents

- 1 How to use wireless schedule?
- 2 DOWNLOAD
- **3 Related Posts**

How to use wireless schedule?


It is suitable for: N100RE, N150RH, N150RT, N151RT, N200RE, N210RE, N300RT, N301RT, N300RH, N302R Plus, A702R, A850R, A3002RU.

Application introduction: This router has a built-in real time clock which can update itself manually or automatically by means of Network Time Protocol (NTP). As a result, you can schedule the router to dialup to the Internet at a specified time, so that users can connect to the Internet only during certain hours.


STEP-1: Check Time Zone Setting

Before using schedule function you have to set your time correctly.

1-1. Click **System->Time Zone Setting** in the sidebar.




1-2. Enable NTP client update and choose the SNTP server, click Save Changes button for saving changes.




STEP-2: Wireless Schedule Setup

2-1. Click Wireless->Wireless Schedule



2-2. Enable the schedule at first, in this section, you can setup the specify time so the WiFi will be on during this period.

The picture is a example, and WiFi will be on from eight o' clock to eighteen o'clock on Sunday.



DOWNLOAD

How to use wireless schedule - [Download PDF]

Manuals+,