Home » Support » LR1200-V2 Quick Installation Guide 🖺

LR1200-V2 Quick Installation Guide

Contents

- 1 LR1200-V2 Quick Installation Guide
- **2 Installation Diagram**
- 3 Interface
- 4 DiagramMethod One: login via


tablet/Cellphone

- 5 Method Two: login via PC
- **6 DOWNLOAD**
- 7 Related Posts


LR1200-V2 Quick Installation Guide

It is suitable for: LR1200-V2

Installation Diagram



Interface



DiagramMethod One: login via tablet/Cellphone


STEP-1:

Activate the WLAN function on your Phone and connect to TOTOLINK_LR1200 or TOTOLINK_LR1200_5G. Then run any Web browser and enter http://itotolink.net in the address bar.

| WLAN | |
|---------------------------------------|---------|
| Turn on or turn off | |
| WLAN | |
| WLAN+ Enhanced Internet experience | On > |
| Available networks | |
| TOTOLINK_LR1200_5G | |
| TOTOLINK_LR1200 | |
| TOTOLINK_TestA Encrypted | নি |
| TOTOLINK_TestB Saved | <u></u> |


STEP-2:

Enter admin for the password and then click LOGIN.



STEP-3:

Click Quick Setup.




STEP-4:

Time Zone setting. According to your location, please click the Time Zone to choose a correct one from the list, then click Next.




STEP-5:

Internet Setting. Choose a suitable connection type from the list and fill in the information required, then click Next.



STEP-6:

Wireless Setting. Create passwords for 2.4G and 5G Wi-Fi (Here users could also revise the default Wi-Fi name) and then click Next.



STEP-7:

For security, please create a new Login Password for your router, then click Next.




STEP-8:


The coming page is the Summary information for your setting. Please remember your Wi-Fi Name and Password, then click Done.



STEP-9:

It takes several seconds to save the settings and then your router will restart automatically. This time your Phone will be disconnected from the router. Please back to the WLAN list of your phone to choose the new Wi-Fi name and input the correct password. Now, you could enjoy the Wi-Fi.






Method Two: login via PC

STEP-1:

Connect your computer to the router by cable or wireless. Then run any Web browser and enter http://itotolink.net in the address bar.


STEP-2:


Enter admin for the password and then click LOGIN.





STEP-3:


Click Quick Setup.











| LR1200-V2 Quick Installation Guide – [Download PDF] | | | | | | | |
|---|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| llanuals+, | | | | | | | |