Home » TOTOLINK » N300RT Wireless SSID Password Settings 12

N300RT Wireless SSID Password Settings

Contents

- 1 N300RT Wireless SSID Password Settings
- 2 Application introduction:
- 3 Settings
 - 3.1 Questions and Answers
 - 3.2 Q1: Should I restart the router after setup wireless
- information?
- **4 DOWNLOAD**
- **5 Related Posts**

N300RT Wireless SSID Password Settings

It is suitable for: N100RE, N150RH, N150RT, N151RT, N200RE, N210RE, N300RT, N301RT, N300RH, N302R Plus

Application introduction:


The Wireless SSID and password are the basic information for you to connect Wi-Fi network. But sometimes you may forget or want to change them regularly, so here we will guide you how to check or modify the wireless SSID and password.

Settings

STEP-1: Enter the setup interface

Open a browser, enter 192.168.0.1. Input User Name and password (default admin/admin) on login management interface, as follows:


Note: The default access address varies depending on the actual situation. Please find it on the bottom label of the product.



STEP-2: View or modify the wireless parameters


2-1. Check or modify in Easy Setup page.

Login management interface, first enter the **Easy Setup** interface, you can see **wireless settings**, as follows:




2-2. Check and modify In the Advanced Setup


If you also need to set more parameters for WiFi, you can enter the Advanced Setup interface to set up.



Set the SSID and password according to the following procedure.



You are also able to set the Channel Width, Date Rate, RF Output Power.



Q1: Should I restart the router after setup wireless information?
A: After setting, you need to wait a few seconds for the wireless information to take effect.
DOWNLOAD
N300RT Wireless SSID Password Settings – [DOwnload PDF]

Manuals+,