



TOTOLINK S505G Desktop Gigabit Switch Installation Guide

[Home](#) » [TOTOLINK](#) » TOTOLINK S505G Desktop Gigabit Switch Installation Guide 

TOTOLINK S505G Desktop Gigabit Switch



Contents


- [1 Before Installation](#)
 - [1.1 LED Indicators](#)
- [2 Hardware Installation](#)
- [3 Specifications](#)
- [4 Customer Support](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

Before Installation



Checking Package Contents
Appearance

S505G

- 1*5-Port 10/100/1000Mbps Switch
- 1*Power Adapter
- 1*Quick Installation Guide




LED Indicators

LED Indicator	Status	Indication
	On	Lights yellow when the switch is receiving power
	Off	Powered off
	On	Connected to network lights on, data transmission blinks yellow
	Off	Not connected

Hardware Installation

Refer to the application scene graph below:

1. Connect one switch port to anyone of Router’s LAN port.
2. Connect PC’s RJ45 port to one switch port.
3. Plug power adapter into both switch’s DC IN port and outlet.



Specifications


Standards	IEEE 802.3, IEEE 802.3u, IEEE 802.3x
Interface	5*10/100/1000Mbps auto-negotiation RJ-45 Ports (Auto MDI/MDIX)
Network Media	10BASE-T: UTP Cat 3, 4, 5 cable 100BASE-TX/ 1000BASE-T: UTP Cat 5, 5e or above cable
Power Supply	9V DC/0.5A
Backup Bandwidth	10Gbps
MAC Address Table	2K
Advanced Features	Support IGMP Snooping, Giga Port
Transmission Method	Store-and-forward
LED	1* Power, 5*LANs
Dimensions(L x W x H)	93 x 65 x 24mm

Customer Support



The Smartest Network Device

Documents / Resources

	TOTOLINK S505G Desktop Gigabit Switch [pdf] Installation Guide S505G Desktop Gigabit Switch, S505G, Desktop Gigabit Switch, Gigabit Switch, Switch
---	---