



Toucan TSCP05GR Wireless Security Camera User Manual

[Home](#) » [Toucan](#) » Toucan TSCP05GR Wireless Security Camera User Manual



Wireless Security
Camera PRO
USER MANUAL



TSCP05GR

Contents [[hide](#)]

1 Items included

2 Charge your Wireless Security Camera PRO

3 Install your Wireless Security Camera PRO

4 Documents / Resources

4.1 References

5 Related Posts

Items included



Charge your Wireless Security Camera PRO

Open the micro USB plug cover, plug in the micro USB cable to charge the camera.
Recommend to fully charge the device before 1st use.



LED Description

Solid RED	Charging Battery
Solid BLUE	Battery Fully Charged

Setup your Wireless Security Camera PRO

1. Download the Toucan App

Scan QR code or visit www.toucansolution.com/pages/toucan-smart-home-app


Available at Apple © App Store © and Google Play™



<https://www.toucansolution.com/pages/toucan-smart-home-app>

2. Login to the App

Open the app and create a free account.



3. Add your device

Tap the “+” to add a device



4. Connect your device

Press and hold the SET button until LED light on the front blinks blue to enter the setup mode.



Follow the instructions in the Toucan App to complete the setup



LED Description

Flashing BLUE	Setup Mode
Flashing PURPLE	Connecting to cloud server
Flashing RED	Connection Failed

Install your Wireless Security Camera PRO

1. Check WiFi signal at installation area Take the camera to the planned installation area. Tap on the camera in the Toucan App Dashboard to bring up Live View to make sure there is good WiFi signal at the installation area.




2. **Attach the magnetic ball**

Screw the magnetic ball onto the back of the camera




3. Mark the Magnetic Mount's preferred placement

Using the magnetic mount as a template, mark where you want to mount the camera with a pencil.



4. Choose how you want to secure the Magnetic Mount



If using 3M Adhesive only (B), allow 24 to 48 hours curing time before placing the camera onto the Magnetic Mount to ensure maximum bonding strength.

When using just the 3M adhesive (B) to install the Magnetic Mount, apply the adhesive on dry surfaces only. It is suitable for UPVC, wooden or smooth surface door frames. (Not suitable for brick or stone)

5. Place the camera on the Magnetic Mount Place the camera with the ball onto the Magnetic Mount.

It will attach firmly. Adjust camera angle best suited.





<https://www.toucansolution.com>

For detailed setup procedure, please refer to the Toucan website (www.toucansolution.com) or scan the QR code.

Documents / Resources



[Toucan TSCP05GR Wireless Security Camera](#) [pdf] User Manual

LBP05, 2AK7ELBP05, TSCP05GR Wireless Security Camera, TSCP05GR, Wireless Security Camera, Security Camera, Camera

References

- [Wireless Doorbell Camera | Wireless Outdoor Security Camera | Toucan – Toucan Solutions](#)
- [Wireless Doorbell Camera | Wireless Outdoor Security Camera | Toucan – Toucan Solutions](#)
- [Toucan Smart Home App – Toucan Solutions](#)