Home » Touch Lighting Control » Touch Lighting Control WS-C-MINI Touchscreen Mini Color Wall Station Instruction Manual ™

## Touch Lighting Control WS-C-MINI Touchscreen Mini Color Wall Station Instruction Manual

#### **Contents**

- 1 INSTALLATION INSTRUCTIONS
  - 1.1 TOUCHÉ LIGHTING CONTROLS
    - 1.1.1 PART # WS-C-MINI
    - 1.1.2 COLOR MINI WALL STATION
      - 1.1.2.1 SCREEN INFORMATION
      - 1.1.2.2 TIPS / NOTES
      - 1.1.2.3 CLEANING DOS
      - 1.1.2.4 CLEANING DON'TS
  - 1.1.3 COLOR MINI WALL STATION CONNECTIVITY
  - DIAGRAM
- 2 Documents / Resources
- 2.1 References

#### **INSTALLATION INSTRUCTIONS**

# é


## **TOUCHÉ LIGHTING CONTROLS**

PART # WS-C-MINI

**COLOR MINI WALL STATION** 

**SCREEN INFORMATION** 

SYMBOLS AS SHOWN ON SUBMITTAL AND CONSTRUCTION DOCUMENTS






BUS ERROR
ISSUE – CONNECTED TO ROOM MANAGER SMART PORT

- REMOVE FROM CURRENT PORT AND CONNECT TO ROOM MANAGER BRANCH PORT
- THIS WILL NOT APPEAR WHEN CONNECTED TO THE SMARTPACKPACK PLUS




COMMUNICATION ERROR
ISSUE – POWER AND NO COMMUNICATION

- VERIFY SWITCH IS CONNECTED TO BRANCH PORT IF CONNECTED TO ROOM MANAGER
- VERIFY CABLING TERMINATION COLOR CODING



**UNACTIVATED** 

• PRESS AND HOLD ACTIVATE BUTTON



**NO ACTION REQUIRED** 

#### TIPS / NOTES

- WS-C-MINI IS A BRANCH DEVICE WHEN CONNECTED TO A ROOM MANAGER AND A SMART DEVICE
   WHEN CONNECTED TO A SMARTPACK PLUS
- WS-C-MINI CANNOT BE USED WITH A SMARTPACK
- MOUNTS TO SINGLE GANG JUNCTION BOX OR 4 SQUARE BOX WITH SINGLE GANG MUD RING

#### **CLEANING DOS**

- USE ONLY TOUCHSCREEN SAFE CLEANER AND CLEAN MICROFIBER CLOTH
- DAMPEN THE CLEAN MICROFIBER CLOTH AND WIPE SWITCH
- WIPE THE SWITCH DRY WITH A CLEAN MICROFIBER CLOTH


#### CLEANING DON'TS



- USE GLASS CLEANER
- SPRAY SWITCH DIRECTLY WITH CLEANER
- USE PAPER TOWELS


FAILURE TO FOLLOW THESE INSTRUCTIONS WILL DAMAGE THE SWITCH AND VOID THE PRODUCT WARRANTY

**COLOR MINI WALL STATION CONNECTIVITY DIAGRAM** 



## 1. TO NEXT BRANCH DEVICE (AS SHOWN ON FLOOR PLANS)

CABLE TYPES				
LINE ID	DESCRIPTION	TYPE	NOTES	
	BRANCH	CAT 5 (MIN)	TOTAL BRANCH LENGTH NOT TO EXCEED 1000'	



## 1. TO NEXT SMARTNET DEVICE (AS SHOWN ON FLOOR PLANS)

CABLE TYPES				
LINE ID	DESCRIPTION	TYPE	NOTES	
	SMART	CAT 5 (MIN)	TOTAL SMARTNET LENGTH NOT TO EXCEED 400'	

Touché Lighting Controls (a Product of ESI Ventures) A: 2085 Humphrey Street, Fort Wayne, IN 46803

T: 888.841.4356 W: <u>ToucheControls.com</u>

#### **Documents / Resources**



Touch Lighting Control WS-C-MINI Touchscreen Mini Color Wall Station [pdf] Instruction M anual

WS-C-MINI Touchscreen Mini Color Wall Station, WS-C-MINI, Touchscreen Mini Color Wall Station, Mini Color Wall Station, Wall Station, Wall Station, Station

### References

• User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.