

# tp-link Deco X73-DSL Wireless VoIP DSL Deco Router User Guide

Home » tp-link » tp-link Deco X73-DSL Wireless VolP DSL Deco Router User Guide





### **Contents**

- **1 Emergency Number**
- 2 Do Not Disturb
- 3 Call Forwarding
- 4 Call Blocking
- **5 Voice Mail**
- **6 Telephony Devices**
- 7 3-Way Conferencing
- **8 Telephone Operation**

Codes

- 9 Documents / Resources
  - 9.1 References
- **10 Related Posts**

### **Emergency Number**

If you don't dial any number after picking up the handset, the emergency numbers will be dialed automatically.

Your family members in the house can send signals for help when emergencies occur. Pick up the handset without any operation, the emergency number will be dialed out automatically.

### Setup

1. Launch the Deco app, go to "More -> Advanced -> Telephony -> Emergency Number".

- 2. Enable Emergency Number.
- 3. Input the emergency number.

#### Note:

If you have entered several emergency numbers (number 2-5), the phone will call these numbers in order if the previous call is not answered.

### • Login/Reset Instructions

### **Do Not Disturb**

If Do Not Disturb is enabled, all incoming calls will be blocked within the defined timeframe. In this case, the caller will hear a "ringback tone" signal, and the calls will be listed in the call log.

### **Example**

You want to have no telephone ring at a certain period of time.

### Setup

- 1. Launch the Deco app, go to "More -> Advanced -> Telephony -> Do Not Disturb".
- 2. Enable Do Not Disturb.
- 3. Set a timeframe when Do Not Disturb is applied.

### **Call Forwarding**

Forward some incoming calls to a designated telephone number.

#### **Example**

When no one answers the incoming call, it would be forwarded to your mobile phone so that you won't miss it.

#### Setur

Launch the Deco app, go to "More -> Advanced -> Telephony -> Call Forwarding".

#### Note:

- Your telephony provider must support this function.
- There mustn't be any blockings configured for the designated number.

### **Call Blocking**

With this function, you can block certain incoming/outgoing calls. In this case, incoming calls will be listed in the call log.

### **Example**

Block incoming unknown calls or avoid expensive premium services that are called from your line.

#### Setup

Launch the Deco app, go to "More -> Advanced -> Telephony -> Call Blocking".

### **Voice Mail**

With this function, you can allow the caller who is not answered to leave a voice mail.

### **Example**

You're on a vacation and cannot receive any call at the moment. If people who called can leave a voice mail, you would know what was going on when you were absent from home.

### Setup

- 1. Launch the Deco app, go to "More -> Advanced -> Telephony -> Voice Mail".
- 2. Enable Voice Mail.

### Listening to your voice mails at home

There are two ways to listen to your voice mails at home.

On one of your fixed-line telephones, dial \*20.

Launch the Deco app, go to "More -> Advanced -> Telephony -> Voice Mail -> My

### Voice Mail" to listen to your messages.

Listening to your voice mails on the road

- 1. Dial your fixed-line number for incoming calls and wait until the announcement begins.
- 2. Press and hold the \* button to interrupt the announcement.
- 3. Type in your Remote Access PIN. Confirm with the # button.

Now you can listen to your messages.

Button	Function	
1	Listen to the previous message	
2	Listen to the next message	
3	Delete all messages	
#	Exit menu	

### **Telephony Devices**

Add your analog phones to Deco and specify different incoming and outgoing call numbers for them separately.

### **Example**

You have more than one telephony device and you don't want all telephones to ring at the same time when a number is called, then you can add your telephony devices to your Deco and customize rules for each telephony device.

### Setup

- 1. Connect your analog phone to your Deco's RJ11 Analog Phone Port.
- 2. Launch the Deco app, go to "More -> Advanced -> Telephony -> Telephony Devices".
- 3. Choose a phone and customize the settings.

### 3-Way Conferencing

### Usage

- 1. Call the first participant and press the R key during the call.
- 2. Dial the second participant's number.
- 3. Wait until he answers the call and then presses the key sequence . Now you can talk to bot participants.
- 4. To finish the conference call, simply hang up.

### Note:

The conference call will finish as soon as the initiator hangs up.

Button Function	
R 1	The call with the current partner will be terminated and you can talk to the person waiting in the queue.
R 2	Back to the first participant. The other participant is put to wait in the queue. To switch between the two persons, use the key sequence once more.

## **Telephone Operation Codes**

The following codes can be used on telephones connected to your VoIP DSL Deco router.

Code	Description	Function
* 2 0	Listen to voice mail messages	Take your handset and type the code to listen to your voice mail s. Then:  •Press 1 to listen to the previous message.  •Press 2 to listen to the next message.  •Press 3 to delete all messages.
* 3 0	Record a greeting for your vo ice mail	Pick up your phone and dial the code. After you hear the confirm ation tone, you can record your own greeting.
* 6 8	Redial	Pick up your phone and dial the code. Now the last dialed numb er is called again.
* 6 9	Callback	Pick up your phone and dial the code. Now the last number that called you will be called.
* 7 8 * 7 g	Enable Emergency Number Disable Emergency Number	Pick up your phone and dial the code. After you hear the confirm ation code, the function will be enabled or disabled.
* 8 0 * 8 1	Enable "Block anonymous ca Ils" Disable "Block anonymous c alls"	Pick up your phone and dial the code. After you hear the confirm ation code, the function will be enabled or disabled.
* 8 6 * 8 7	Enable "Do Not Disturb" Disa ble "Do Not Disturb"	Pick up your phone and dial the code. After you hear the confirm ation code, the function will be enabled or disabled.
* 9 9	Automatic redial if a line is bu	Pick up the phone, dial the code before the target number and h ang up. The DSL Deco router will call this number until the person is available. Then your phone will ring to indicate that he/she is available. Then pick up your phone to talk to this person. To end automatic redial, simply pick up the phone and hang up.
* *	Call all your phones	Pick up one phone and dial the code. Now all other phones will r ing until one call is answered.

7106509376 REV1.1.0 ©2021 TP-Link <u>www.tp-link.com</u>

### References

• ₱ WiFi Networking Equipment for Home & Business | TP-Link

Manuals+,