



# tp-link LTE Router Installation Guide

[Home](#) » [tp-link](#) » tp-link LTE Router Installation Guide 

## Contents

- 1 Quick Installation Guide
  - 1.1 4G LTE Router
  - 1.2 CONTENTS
    - 1.2.1 English
    - 1.2.2 Connect the Hardware
    - 1.2.3 Enjoy the Internet!
      - 1.2.3.1 English
    - 1.2.4 Customize the 4G LTE Router
    - 1.2.5 FAQ(Frequently Asked Questions)
      - 1.2.5.1 English
      - 1.2.5.2 English
- 2 Documents / Resources
  - 2.1 References
- 3 Related Posts




For technical support, the user guide and more information, please visit <https://www.tp-link.com/support>.  
©2021 TP-Link 7106509142 REV3.0.1

## Quick Installation Guide

4G LTE Router

## CONTENTS

## Connect the Hardware



**Note:** Images are for demonstration only.

1. Position the antennas vertically.

**Note:** For some routers you need to install the antennas manually first.

2. Insert the SIM card into the slot until you hear a click.
3. Turn on the router.



**Enjoy the Internet!**

Connect your device to the router (wired or wireless).

The default SSID and password are printed on the product label at the bottom of the router.

English

## Customize the 4G LTE Router

1. Make sure your computer is connected to the router (via wired or wireless).
2. Enter <http://tplinkmodem.net> or [192.168.1.1](http://192.168.1.1) in the address bar of a web browser. Based on the actual web management login page: use the default **admin** for both username and password or create a new password to log in.
3. Follow the step-by-step instructions on the **Quick Setup** page to complete the initial configuration.

**Note:** The router can also be used (or configured) in wireless router mode for ADSL/Cable connections. For more information, please refer to the User Guide at [www.tp-link.com](http://www.tp-link.com).

## FAQ(Frequently Asked Questions)

**Q1. What can I do if the login page does not appear?**

- Verify that the computer is set to obtain an IP address automatically from the router.
- Verify that <http://tplinkmodem.net> or [192.168.1.1](http://192.168.1.1) is correctly entered in the web browser.
- Use another web browser and try again.
- Reboot your router and try again.
- Disable and then enable the active network adapter and try again.

## Q2. What can I do if I cannot access the internet?

2

English

- Verify that your SIM card is an LTE, WCDMA or GSM card.
- Verify that your SIM card is in your ISP's service area.
- Verify that your SIM card has sufficient credit.
- Check the LAN connection:  
Enter <http://tplinkmodem.net> or [192.168.1.1](http://192.168.1.1) in the address bar of a web browser. If the login page does not appear, refer to FAQ > Q1 and then try again.
- Check your ISP parameters:
  1. Open a web browser and log in to the web management page.
  2. Verify the parameters provided by your ISP are correctly entered. If the parameters are incorrect, create a new profile with the correct parameters.
- Check the PIN settings:
  1. Open a web browser and log in to the web management page.
  2. Verify if PIN is required. If it is, enter the correct PIN provided by your ISP.
- Check the Data Limit:
  1. Open a web browser and log in to the web management page.
  2. Verify if the total used data exceeds the total allowance. If it does, correct the total allowance and set the total used data to 0, or disable the data limit.
- Check the Mobile Data:
  1. Open a web browser and log in to the web management page.
  2. Enable the mobile data to access the internet.

- Check the Data Roaming:

1. Confirm with your ISP if you are in a roaming service area. If you are, open a web browser and log into the web management page.
2. Enable the data roaming to access the internet.

### Q3. How to restore the router to its factory default settings?

- With the router powered on, press and hold the WPS/RESET button on the rear panel of the router until the Power LED starts flashing. The router will restore and reboot automatically.
- Log in to the web management page of the router to restore the router to its factory defaults.

### Q4. What can I do if I forget the password of the web management page?

- Refer to FAQ>Q3 to restore the router and use admin for both username and password or create a new password to log in.

### Q5. What can I do if I forget my wireless network password?

- The default wireless password is printed on the product label of the router.
- If the default wireless password has been changed, log in to the router's web management page and retrieve or reset your password.

**Note:** For more troubleshooting help, please refer to FAQ on our website: <https://www.tp-link.com>.


4

#### **English:**







TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU and (EU)2015/863.

The original EU declaration of conformity may be found at <https://www.tp-link.com/en/ce>.

### Documents / Resources

	<a href="#">tp-link LTE Router</a> [pdf] Installation Guide LTE Router, 4G LTE Router
---	--

### References

-  [Link: Simple, secure one-click payments](#)
-  [Trying to configure the Modem? | TP-Link](#)
-  [WiFi Networking Equipment for Home & Business | TP-Link](#)
-  [TP-Link Polska – Rozwiązania Wi-Fi dla domu i biznesu](#)
-  [WiFi Networking Equipment for Home & Business | TP-Link](#)
-  [CE Regulatory Compliance | TP-Link](#)

- [!\[\]\(83eb2aa26b610eb6a9dca7cf4702d681\_img.jpg\) CE | TP-Link Magyarország](#)
- [!\[\]\(94dfacbf937cdd7da4837a6fcd8fc785\_img.jpg\) Часто задаваемые вопросы \(FAQ\) | TP-Link Россия](#)
- [!\[\]\(dae8c3c5fa7c80febd6526a5e8a853bf\_img.jpg\) TP-Link Product Support - Wireless Networking Equipment Support](#)

Manuals+.