



tp-link P100 Mini Smart Wifi Socket User Guide

[Home](#) » [tp-link](#) » tp-link P100 Mini Smart Wifi Socket User Guide 

Contents

- 1 [tp-link P100 Mini Smart Wifi Socket](#)
- 2 [Documents / Resources](#)
- 3 [Related Posts](#)



tp-link P100 Mini Smart Wifi Socket



Getting Started

1. Get the Tapo app from the Apple App Store or Google Play.
2. Follow the instructions in the Tapo app to complete the setup.

Supported Load Type for UK Version:

220-240Vac, 50/60Hz, 13A Resistive Load

220-240Vac, 50/60Hz, 2.0FLA/13LRA*, Motor Load

*FLA=Full Load Ampere; LRA=Lock Rotor Ampere.

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU and (EU) 2015/863. The original EU declaration of conformity may be found at <https://www.tapo.com/support/ce/>.

- The devices are not intended for use in locations where the temperature may be less than actual room conditions, such as unheated warehouses or garages.
- For passthrough devices, plug the power strips into the integrated electrical sockets of the devices, but devices of the same or another type not be stacked in normal use.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk. No restrictions exist in the use of radio frequencies or frequency bands in all EU member states and EFTA countries.

Warranty

For more information about warranty, please visit <https://www.tapo.com/support/>

Documents / Resources



[tp-link P100 Mini Smart Wifi Socket](#) [pdf] User Guide
P100, Mini Smart Wifi Socket

