



tp-link Range Extender Power LED Installation Guide

[Home](#) » [tp-link](#) » tp-link Range Extender Power LED Installation Guide 

Contents

- 1 [tp-link Range Extender Power LED](#)
- 2 [Power On](#)
- 3 [Set Up](#)
 - 3.1 [Via the Tether App](#)
- 4 [More Setup Methods](#)
 - 4.1 [Via a Web Browser](#)
 - 4.2 [Via the WPS Button](#)
- 5 [Relocate](#)
- 6 [Manage the Extender](#)
 - 6.1 [Method 1: Via the Tether App](#)
 - 6.2 [Method 2: Via a Web Browser](#)
- 7 [LED Explanation](#)
- 8 [FAQS](#)
- 9 [Safety Information](#)
- 10 [Documents / Resources](#)
 - 10.1 [References](#)
- 11 [Related Posts](#)




tp-link Range Extender Power LED



Power On

Plug the extender into a power outlet next to your router. Wait until its Power LED turns solid on.



Set Up

Via the Tether App

1. Get the up-to-date Tether app from the Apple App Store or Google Play, or simply scan the QR code.




or



Tether


Scan for Tether

2. Launch the Tether app and log in with your TP-Link ID. If you don't have an account, create one first.




3. Tap the button and select Range Extender.

Note: If you cannot find your device, please refer to FAQ > Q1.



4. Follow app instructions to complete the setup. The Signal LED should turn solid on, indicating successful connection to your router



More Setup Methods


Via a Web Browser

- Connect your computer or smartphone to the extender's network TP-Link_Extender.
- Visit <http://tplinkrepeater.net> or <http://192.168.0.254> in a web browser. Create a password to log in.
- Follow web instructions to complete the setup.

Via the WPS Button

- Press the WPS button on your router.
- Within 2 minutes, press the WPS button on the extender for 1 second. The Signal LED should change from blinking to solid on, indicating successful connection.
- If the extender connects to a dual-band router, repeat steps 1 and 2 to connect to the other band.

Relocate




1. Plug in the extender about halfway between your router and the Wi-Fi dead zone. The location you choose must be within the range of your router.

2. Wait for about 2 minutes until the Signal LED turns solid blue. If it doesn't, relocate the extender closer to the router to achieve better signal quality.

Tip: For more intuitive location assistant, access extender settings via the Tether app and go to Tools > Location Assistant.

Enjoy!



Connect your devices to the extender wirelessly or via an Ethernet cable, then enjoy the internet. The password of your extended network is the same as your host router.

Tip: You can also set up the extender in Access Point mode to transform your existing wired network to a wireless one. For details, refer to the user guide at <https://www.tp-link.com/support/download>

Manage the Extender

After setup, you can manage the extender via any of the methods below.

Note: If your extender and router use the same network name, Method 1 is recommended.

Method 1: Via the Tether App

1. Connect your smartphone to the extender's or router's network.
2. Launch the Tether app, select your extender, and log in.
3. Manage the extender as needed.

Method 2: Via a Web Browser

1. Connect your computer or smartphone to the extender's network. If you are using a computer, unplug the Ethernet cable if any.
2. Launch a web browser, enter <http://tplinkrepeater.net> in the address bar, and log in.
3. Manage the extender as needed.

OneMesh™ with Seamless Roaming

TP-Link OneMesh router and extenders work together to form one unified Wi-Fi network. Walk through your home and stay connected with the fastest possible speeds thanks to OneMesh's seamless coverage.

Unified Wi-Fi Network

Router and extenders share the same wireless settings, including network name, password, access control settings and more.

Seamless Roaming


Devices automatically switch between your router and extenders as you move through your home for the fastest possible speeds.

Easy Setup and Management

Set up a OneMesh network with a push of WPS buttons. Manage all network devices on the Tether app or at your router's web management page.

To check full list of TP-Link OneMesh devices, scan the QR code, or visit <https://www.tp-link.com/One-Mesh/compatibility>

LED Explanation




| LED | Status | Indication (For Range Extender Mode) |
|--------|------------|--|
| Power | On/Off | The extender is on or off. |
| | Blinking | The system is starting up or firmware upgrade is in progress. |
| Signal | Solid blue | The extender is connected to your router's wireless network and is in a suitable location. |
| | Solid red | The extender is receiving a weak signal. Try relocating it closer to your router. |
| | Blinking | WPS connection is in progress. |
| | Off | No wireless connection is established. |
| 2.4GHz | On/Off | The extender is connected or not connected to the 2.4GHz wireless network of your router. |
| 5GHz | On/Off | The extender is connected or not connected to the 5GHz wireless network of your router. |

FAQS


Q1. What should I do if the Tether app cannot find my device?

Connect your smartphone to the extender's network TP-Link_Extender.



Launch the Tether app, and select your extender.

Tip: If you have connected to the extender's Wi-Fi but still cannot find your device, turn off your cellular data.



Follow app instructions to complete the setup.


If you are still having problems, contact our technical support.

Q2. What should I do if the Signal LED doesn't turn solid on after completing setup via the Tether app or web browser?

- You may have entered incorrect Wi-Fi passwords for your host networks during the configuration. Check the passwords and try again.
- Make sure the extender is close to your router, preferably within 16 feet, and away from large electrical appliances.
- If you have enabled wireless MAC filtering, wireless access control, or access control list (ACL) on your router, disable them first, then follow any method on the front page to complete the configuration.
- Try setting up via the WPS button.
- Reset the extender and go through the configuration again.

Q3. How do I reset the extender?

- With the extender powered on, use a pin to press the RESET button for 1 second. The extender will reboot.




Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use the device where wireless devices are not allowed.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.



Documents / Resources

| | |
|---|---|
|  | tp-link Range Extender Power LED [pdf] Installation Guide Range Extender Power LED |
|---|---|

References

- [🌐](#)
- [🔗 Trying to Configure the Range Extender? | TP-Link](#)
- [🔗 TP-Link Community](#)
- [🔗 CE Regulatory Compliance | TP-Link](#)
- [🔗 TP-Link OneMesh Devices](#)
- [🔗 TP-Link Product Support - Wireless Networking Equipment Support](#)
- [🔗 Download Center | TP-Link](#)
- [🔗 Support Videos | TP-Link](#)