

tp-link SERCOMM DM1000 Mesh Wi-Fi Router User Guide

Contents

1 SERCOMM DM1000 Mesh Wi-Fi Router

1.1 QUICK START GUIDE MODEM: SERCOMM DM1000 & MESH WI-FI ROUTER: TP-LINK DECO X10

1.2 1 CHECK THE BOX CONTENTS Look in the box and make sure you have the following:

1.3 2 CONNECT THE MODEM TO THE CABLE OUTLE

1.4 3 CONNECT THE POWER ADAPTER TO THE MODEM

1.5 4 CONNECT THE MODEM TO THE ROUTER

1.6 5 CONNECT THE POWER ADAPTER TO THE ROUTER

1.7 6 DOWNLOAD AND INSTALL THE DECO APP

1.8 To download the full manual, please visit

2 Documents / Resources

2.1 References

3 Related Posts

SERCOMM DM1000 Mesh Wi-Fi Router

QUICK START GUIDE MODEM: SERCOMM DM1000 & MESH WI-FI ROUTER: TP-LINK DECO X10

1 CHECK THE BOX CONTENTS

Look in the box and make sure you have the following:



2 CONNECT THE MODEM TO THE CABLE OUTLE

Connect the coaxial cable from the modem to the cable outlet as indicated below.



3 CONNECT THE POWER ADAPTER TO THE MODEM

Connect the power adapter DIRECTLY from the wall outlet to the modem as indicated below.



4 CONNECT THE MODEM TO THE ROUTER

Connect the ethernet cable from the modem's LAN port to the router's port as indicated below



5 CONNECT THE POWER ADAPTER TO THE ROUTER

Connect the power adapter DIRECTLY from the wall outlet to the router as indicated below



6 DOWNLOAD AND INSTALL THE DECO APP

Download the TP-Link Deco app for iOS or Android. The app will walk you through the setup



Need Help?

For answers to frequently asked questions (FAQs) and technical support, please go to

- <https://www.tp-link.com>
- Navigate to Deco's support page
- [the Deco app](#)

Swipe right at the main page and select [Help](#) from the menu.

To download the full manual, please visit

SERCOMM DM1000

<https://www.carrytel.ca/download/sercommdm1000.pdf>

TP-LINK DECO X20

<http://www.carrytel.ca/download/decox20.pdf>

If you need help to set up the equipment, please contact us at [645-560-4448](tel:645-560-4448) and go to Line 2 for Technical Support

Documents / Resources

A thumbnail image of the user guide for the SERCOMM DM1000 Mesh Wi-Fi Router. It shows a series of numbered steps (1-6) with corresponding illustrations of the router and its setup process.	<p>tp-link SERCOMM DM1000 Mesh Wi-Fi Router [pdf] User Guide SERCOMM DM1000 Mesh Wi-Fi Router, SERCOMM DM1000, Mesh Wi-Fi Router, Wi-Fi Router, Router</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.