

tp-link WIF-TP-00030 VIGI Network Camera User Guide

Home » tp-link » tp-link WIF-TP-00030 VIGI Network Camera User Guide 1





Quick Start Guide VIGI Network Camera

Images may differ from your actual products.

For technical support, the user guide and more information, please visit https://www.tp-link.com/support. © 2022 TP-Link 7106509974 REV1.3.0

Contents

- 1 Mount Your Camera
- 2 Use Your Camera with an NVR
- 3 More Management Methods
- 4 Method 1: Via the VIGI App
- 5 Method 2: Via a Web Browser
- 6 Method 3: Via the VIGI Security Manager (Windows


- 7 Documents / Resources
 - 7.1 References

Mount Your Camera

Mount your camera according to the diagrams in the Quick Start Guide included in the package.

Use Your Camera with an NVR

The camera works with an NVR for easier batch access and management. Here we use a VIGI NVR as an example.



- 1. Connect your cameras to the same network as your NVR (as shown above).
- 2. Power on your cameras with the PoE power supply or an external power supply.

Note: The camera's standard power supply is 12V DC or PoE (802.3af/at). The power source should comply with Power Source Class 2 (PS2) or Limited Power Source(LPS) of IEC 62368-1. Some models do not support DC power supply. You can check the detailed specifications on the product page at https://www.tplink.com/.

3. Add your cameras with the NVR.

Before you start, make sure the NVR is working properly. Then add your camera with the NVR.

- 1) Go to the NVR management page, right click on the screen, and click Add Camera.
- 2) Select your camera and click + to add your camera directly. If you have disabled Plug & Play on your NVR, create a password or use a preset password for your camera.
- Done! You can now view live video and manage cameras.

Using your cameras with other NVR brands

- 1. Power on your cameras and connect them to the network.
- 2. Activate the camera using the VIGI Security Manager or VIGI app (refer to the next section).
- 3. Refer to the NVR's User Manual to add cameras.

More Management Methods

You can also access and manage your cameras via any of the methods below.

Method 1: Via the VIGI App

Remotely view live video, manage cameras, and get instant alerts.

1. Download and install the VIGI app.



https://www.tp-link.com/app/qrcode/?app=vigi

- 2. Open the VIGI app and log in with your TP-Link ID. If you don't have an account, sign up first.
- 3. Tap the + button on the top right and follow the app instructions to activate and add your cameras.

Method 2: Via a Web Browser

Note: Some models do not support web managment. You can check the detailed specifications on the product page at https://www.tp-link.com/.

View live video and modify camera settings via a web browser.

- 1. Find the camera's IP address on your router's client page.
- On your local computer, open a web browser and enter https://cameras IP address (https://192.168.0.60 by default).
- 3. Select your Country/Region and Time Zone.
- Set a password to activate the camera.
 Done. You can view the live video on the Preview page, and go to the Settings page to change camera settings.

Method 3: Via the VIGI Security Manager (Windows only)

View live video and modify camera settings on your computer.

- 1. Download the VIGI Security Manager on your computer at https://www.tp-link.com/download-center/
- 2. Install the VIGI Security Manager and open it.
- 3. Cameras on the same network as your computer can be automatically discovered. Go to Settings > Discovered Devices, click + Add to activate your discovered cameras by setting passwords, and follow the instructions to add your cameras.

For frequently asked questions, please refer to https://www.tp-link.com/support/faq/2850/



Documents / Resources



tp-link WIF-TP-00030 VIGI Network Camera [pdf] User Guide WIF-TP-00030, WIF-TP-00030 VIGI Network Camera, VIGI Network Camera, Network Camera, Camera

References

• User Manual

Manuals+, Privacy Policy