



Contents [[hide](#)]

[1 TRACEABLE 99M, 59S Timer](#)

[2 Usage Instructions:](#)

[2.1 Before Using:](#)

[2.2 Countdown Timing:](#)

[2.3 Timeout:](#)

[3 All Operational Difficulties:](#)

[4 Battery Replacement:](#)

[4.1 Specifications:](#)

[5 WARRANTY, SERVICE, OR RECALIBRATION](#)

[6 FAQ:](#)

[6.1 Q: How do I turn off the alarm manually?](#)

[6.2 Q: What should I do if the timer does not function properly?](#)

[6.3 Documents / Resources](#)

[6.3.1 References](#)

[6.4 Related Posts](#)

TRACEABLE 99M, 59S Timer



INSTRUCTION MANUAL

Usage Instructions:

Before Using:

Remove the insulating tab from the battery compartment or insert a battery to activate the device. Refer to the Battery Replacement section for detailed instructions.

Countdown Timing:

1. Press both MIN and SEC buttons simultaneously to set the desired time.
2. Press the START/STOP button to start the countdown.
3. During countdown, the display will show the remaining time.
4. When the timer reaches 00:00, the alarm will sound for 30 seconds.
5. To manually turn off the alarm, press the START/STOP button.

The display will return to the previously programmed time.

Timeout:

1. The timing process can be paused at any time by pressing the START/STOP button once.
2. To resume timing, press the START/STOP button again.

Note: During timeout, additional minutes and seconds can be added to the remaining time on the display.

All Operational Difficulties:

If the timer does not function properly, consider replacing the battery with a new high-quality one. Low battery power can cause operational difficulties. Refer to the Battery Replacement section for instructions.

Battery Replacement:

If you experience incorrect display, no display, or operational issues, it may be time to replace the battery. Follow these steps:

1. Slide the battery compartment door on the back of the unit in the direction of the arrow to open it.
2. Replace the worn battery with a new AAA alkaline battery following the polarity symbols in the compartment.
3. Replace the battery cover. Replacement battery Cat. No. 1105.

Specifications:

- **Display:** minutes and seconds
- **Accuracy:** 0.01%
- **Resolution:** 1 second
- **Timing Channels:** one
- **Timing Capacity:** 1 second to 99 minutes, 59 seconds
- **Alarm:** Audible alarm sounds for 30 seconds
- **Memory:** Automatic recall of last programmed time
- **Functions:** Countdown timing
- **Attachments:** Clip, magnetic back, and stand
- **Size:**

- **Weight:** 2 oz

WARRANTY, SERVICE, OR RECALIBRATION

For warranty, service, or recalibration, contact:

TRACEABLE® PRODUCTS

12554 Old Galveston Rd. Suite B230

Webster, Texas 77598 USA

- Ph. 281 482-1714
- Fax 281 482-9448
- E-mail support@traceable.com
- www.traceable.com

Traceable® Products are ISO 9001:2015 Quality-Certified by DNV and ISO/IEC 17025:2017 accredited as a Calibration Laboratory by A2LA.

Cat. No. 5028

Traceable® and is a registered trademark of Cole-Parmer.

©2020 Traceable® Products. 92-5028-00 Rev. 6 062620

FAQ:


Q: How do I turn off the alarm manually?

A: You can manually turn off the alarm by pressing the START/STOP button. The display will return to the previously programmed time.

Q: What should I do if the timer does not function properly?

A: If you experience operational difficulties, consider replacing the battery with a new high-quality one as low battery power can cause issues. Refer to the Battery Replacement section for detailed instructions.

Documents / Resources

	<p>TRACEABLE 99M, 59S Timer [pdf] Instructions</p> <p>99M 59S Timer, 99M 59S, Timer</p>
--	---

References

- [User Manual](#)

Related Posts



[CLEANFIX 214578 Timer Instructions](#)

214578 Timer Instructions Work instructions: Replace timer on Cleanfix control unit In addition to this manual you will...



[TRACEABLE 5007CC Lab-Top Timer Instructions](#)

TRACEABLE® LAB-TOP TIMER INSTRUCTIONS SPECIFICATIONS: Display: 1/2" 6-digit LCD Timing Capacity: 23 hr, 59 min, 59 sec Resolution:...



[CABANAZ C1201303 Magnetic Kitchen Timer Instructions](#)

Instructions Instruction A- Wind up the Kitchentimer to 58 minutes to activate the bell B- Turn it back...



[TRACEABLE Solar-powered Thermometer Instructions](#)

TRACEABLE® SOLAR-POWERED THERMOMETER INSTRUCTIONS SPECIFICATIONS Display: 1/2" high 4-Digit LCD Probe Range: -58.0 to 158.0°F/-50.0 to

70.0°C Resolution:...

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.