

tracer S1 ANC TWS BT Wireless Headset



tracer S1 ANC TWS BT Wireless Headset Instruction Manual

[Home](#) » [Tracer](#) » tracer S1 ANC TWS BT Wireless Headset Instruction Manual 

Contents

- [1 tracer S1 ANC TWS BT Wireless Headset](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Included in the package](#)
- [5 Product specifications](#)
- [6 How to use](#)
- [7 Precautions](#)
- [8 FAQ](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)



tracer S1 ANC TWS BT Wireless Headset



Specifications

- **Brand:** Tracer
- **Model:** S1 ANC TWS BT
- **Type:** Wireless Headset
- **Connectivity:** Bluetooth
- **Charging Port:** USB-C
- **Charging Voltage:** DC 5V

Product Usage Instructions

Turning On/Off and Pairing the Earphones

1. Remove the earphones from the case to turn them on and pair automatically.
2. To turn off the earphones, place them back in the charging dock.

Pairing

1. Once turned on, the earphones will flash white and blue alternately, indicating pairing mode.
2. In your phone's Bluetooth settings, search for "Tracer S1" to pair with the earphones.
3. Upon successful pairing, you will hear a "connected" message in English.

Volume Control

To decrease volume, press and hold the multifunction button on the right earphone for 3 seconds. To increase volume, do the same on the left earphone.

Included in the package

1. TWS Earphones * 2
2. Charging dock * 1
3. User manual * 1
4. Type-C charging cable *1

Product specifications

- **Bluetooth version:** 5.3
- **Working range:** 10M
- Supports ANC+ENC+Transparent mode+hands free functions
- **Battery capacity:** 40/300mAh
- **Frequency:** 20HZ—20KHZ
- **SNR:** >90dB
- **Mic sensitivity:** -38±2dB
- **ANC sensitivity:** 20dB
- **Playing time:** about 6 hrs
- **Talking time:** 4-5 hrs
- **Charging time:** about 2 hrs
- **Product weight:** 39g

How to use

Turn On / Off the Earphones and Synchronize: Take out the earphones and the earphones will turn on and synchronize pairing automatically, put the earphones inside the charging dock, and they will be off automatically.

True Wireless Mode Pairing

1. After powering on, the blue and white lights of both headsets will flash alternatively and quickly, and both headsets will connect automatically.
2. After being paired successfully, open your phone's Bluetooth and search, search the pairing name "TRACER S1" to pair and connect. Once it's successfully paired with your mobile phone, you will hear "connected"

Play / Pause music

Short press the multifunction button of any earphone.

Volume Control

Long press the right earphone multifunction button 3 seconds to decrease the volume, and long press the left earphone multifunction button 3 seconds to increase the volume.

Next / Previous track

Press the right earphone multifunction button two times to skip to the next track, and press the left earphone multifunction button two times to skip to the previous track.

Answer / End a call

Press the multifunction button of any earphone.

Reject a call:

Long press the multifunction button of any earphone.

Enter Voice Assistant Mode

Press the left earphone multifunction button 3 times to enter Voice Assistant Mode.

Enter Transparent Mode or ANC mode

In the connected state, press the right earphone multifunction button 3 times until the tone “transparent mode or ANC mode” appears.

Enter game Mode or music mode

In the connected state, press the right earphone multifunction button 4 times until the tone “game mode or music mode” appears.

Charging

- Charger not included.
- The charging voltage of the headphone case is DC 5V.
- The power provided by the charger must be between the minimum 0.175 W required by the radio device and the maximum 1.5 W to achieve the maximum charging speed.

**1. To charge the earphones**

Place the earphones in the sockets of the charging dock correctly, and the earphones will be charged automatically. The white light will be on when the earphones are charging, and the white light will go off if the earphones are fully charged.

2. To charge the charging dock

Connect the Type-C charging cable to the computer / AC Adapter and connect the other end of the cable to the charging port of the Charging dock. The white light is flashing when the charging dock is charging; the white light will be fixed when fully charged.

Precautions

- Charger not included.
- The charging voltage of the headphone case is DC 5V.
- The power provided by the charger must be between the minimum 0.175 W required by the radio device and the maximum 1.5 W to achieve the maximum charging speed.
- Please pay attention to the use of high-quality chargers or computer port charging for the product, must not use cheap and poor-quality chargers.
- Bluetooth Earphones are affected by the environment and connection distance. Please do not use them in environments with strong electromagnetic interference and radiation.

- Please do not put the Bluetooth earphone in the water or beat it, which will cause damage to the product.
- If the Bluetooth Earphone is not used for a long time, please charge it monthly to prevent it from starting due to lack of power.
- We may upgrade the software, hardware, or appearance of this product without notice, please refer to the actual product.

DISPOSAL



Crossed-out waste bin symbol placed on the equipment, packaging or documents attached to it means that the product must not be disposed of with other products' waste. Waste equipment may contain substances having toxic and carcinogenic properties, dangerous to human health and life, and also poisonous soil and groundwater. User's responsibility is to hand over used equipment to a designated location collection point for proper processing.

More information about device disposal points can be obtained from local authorities and waste disposal companies and where you purchased this product.

The household plays an important role in contributing to the reuse and recovery of raw materials, including recycling, and used equipment. On this

At this stage, attitudes are formed that influence the preservation of the common good, which is a clean environment.

Producent

Megabajt Sp. z o.o., ul. Rydygiera 8, 01-793 Warszawa

FAQ

- **Q: How do I charge the earphones?**
 - A: The charging dock requires a USB-C connection to a power source with a voltage of DC 5V. Ensure a power output between 0.175W and 1.5W for optimal charging speed.
- **Q: How do I know when the charging dock is fully charged?**
 - A: While charging, the white indicator light on the dock will flash. When the light stays steady, it indicates a full charge.

Documents / Resources

	<p>tracer S1 ANC TWS BT Wireless Headset [pdf] Instruction Manual S1 ANC TWS BT Wireless Headset, S1 ANC TWS BT, Wireless Headset, Headset</p>
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.