

Tracer Stripe TWS Bluetooth Speaker



Tracer Stripe TWS Bluetooth Speaker User Manual

[Home](#) » [Tracer](#) » Tracer Stripe TWS Bluetooth Speaker User Manual 

Contents

- [1 Tracer Stripe TWS Bluetooth Speaker](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 OVERVIEW](#)
- [5 Points for attention](#)
- [6 BLUETOOTH MODE](#)
- [7 USB PLAYBACK MODE](#)
- [8 LIGHT EFFECT](#)
- [9 AUX IN MODE](#)
- [10 FM MODE](#)
- [11 DISPOSAL](#)
- [12 FAQ](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)
- [14 Related Posts](#)



Tracer Stripe TWS Bluetooth Speaker



Specifications


- **Product Name:** Tracer Stripe TWS
- **Model:** Tracer Stripe TWS
- **Product Size:** Not specified
- **Product Weight:** 505 g
- **Bluetooth Transmission Range:** 10 m
- **Play Time:** 5 hours
- **Charging Time:** 2.3 hours
- **Battery Capacity:** 3.7 V / 1200 mAh
- **Input:** USB-C 5V / 500 mA
- **Maximum Transmitter Power (E.I.R.P):** 20 dBm

Product Usage Instructions

- **Bluetooth Mode**
 - In Bluetooth mode, you can connect your device wirelessly to the speaker.
- **TF Card Mode**
 - This mode allows you to play music from a TF card. Use short presses to switch tracks and control volume.
- **USB Playback Mode**
 - Switch to USB playback mode to play music from a USB device. Control track selection and volume with short presses.
- **AUX In Mode**
 - This mode allows you to connect external devices via the AUX port.
- **FM Mode**
 - Switch to FM radio mode to listen to radio stations. Control volume and track selection using the

designated buttons.

OVERVIEW





Points for attention

- Do not hit or crush it seriously.
- Do not contact benzene, diluent, or other chemicals.
- Do not use a nearby strong magnetic field or electric field.
- Avoid direct rays or heating appliances.
- Do not disassemble, repair, or modify.
- Do not listen at large volume for long periods, so as not to injure the hearing.
- Do not clean the speaker with water and don't immerse the speaker in the water. This speaker only has a water prayer prevention function. If the speaker is not in the right way and causes any quality problems, do not support a warranty. Kindly note the above! Please clean the speaker with a slightly damp cloth.
- When using cycling, driving a car or motorcycle, Please don't stand in the rain for a long time.
- When using at low voltage, it may distort sound and please charge it in time.
- Bluetooth is compatible with common smartphones and tablets, but depending on the device or application you use, may not be able to support a particular feature.


Product Name	Bluetooth Speaker
Model	Tracer Stripe TWS
Product size	190x Ø 90 mm
Product weight	505 g
Bluetooth transmission	≥ 10 m
Play time	5h
Charging time	2,3 h
Battery capacity	3,7 V / 1200 mAh
Input	USB-C 5 V / 500 mA
Maximum Transmitter Power (E.I.R.P) ≤20 dBm	
The range of which the device operates: 2400–2483,5 MHz	

BLUETOOTH MODE





- **Bluetooth version:** 5.0 supports HSP, HFP, A2DP, and AVRCP.

- **ON/OFF:** Long press  , to turn On/Off the speaker.
- **Bluetooth pairing:** When the blue light blinks fast, the speaker is ready for pairing, search for Tracer Stripe on your phone and pair it. blue light becomes stable after successful pairing.
- Long press  to disconnect bluetooth.





TWS

- Long press  each one to enter TWS mode.



TF CARD MODE

- When the TF Card is inserted in the TF card slot, the speaker will switch to TF card mode automatically. Or short press M to switch to TF card mode.
- Blue light keeps blinking slowly while music is being played.
- Short press  /  for PREV /NEXT.
- Long press  /  control the volume

USB PLAYBACK MODE

- The speaker will switch to USB playback mode automatically after inserting the USB. Or short press M to switch to USB playback mode.
- The blue light keeps blinking while music is being played.
- Short press  /  for PREV /NEXT.
- Long press  /  control the volume.





LIGHT EFFECT







- Short press  Turn on the light, then press to turn off the light.
- Long press  Toggle Lighting Effects (11 effects).

AUX IN MODE

- Plug in the 3.5mm audio cable to enter Aux-in mode, or short press M to switch to Aux-in mode.
- Blue light keeps blinking slowly while music is being played

FM MODE

- Short press M to switch to FM mode.
- Long press  /  control the volume.
- Short press  /  for PREV /NEXT.

Button	Action
	Long press for V+, Short press for Next
	Long press for V-, Short press for Prev
	Long press for switch Short press for play/pause
	Short press switching mode Lona Press: disconnect Bluetooth connection
	Short press to switch for candle blinking light and stable light
	Type C charging port

- **Minimum charging power:** 0.5W
- **Maximum charging power:** 6W
- No charger is included in the set.

The power supplied by the charger must be between the minimum of 0.5W required by the radio device and a maximum of 6W to achieve maximum charging speed.



DISPOSAL



The symbol of a crossed-out wheeled bin placed on electronic or electrical equipment, its packaging, or accompanying documents means that the product may not be thrown out together with other waste. Used equipment may contain substances with toxic and carcinogenic properties, hazardous to human health and life, and poisoning the soil and groundwater. It is the user's responsibility to hand over the used equipment to a designated collection point for its proper processing. For more information on recycling electronic and electrical equipment, please contact your local authorities, waste disposal services, and the place where you purchased this product.

The household plays an important role in contributing to the reuse and recovery of secondary raw materials, including recycling, and waste equipment. At this stage, attitudes are formed that affect the preservation of the common good, which is a clean natural environment.

FAQ


- **Q: What is the charging power range for this device?**
 - A: The minimum charging power is 0.5W, and the maximum charging power is 6W. Ensure your charger

provides power within this range for optimal charging speed.

Producent

Megabajt Sp. z o.o., ul. Rydygiera 8, 01-793 Warszawa

Documents / Resources



References

- User Manual

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.