



TREANSNECT Audio Transmitter/ Receiver Adapter BC108 User Manual

[Home](#) » [TREANSNECT](#) » TREANSNECT Audio Transmitter/ Receiver Adapter BC108 User Manual 



IS CONNECTING TO YOU

Bluetooth 4.2 Audio Transmitter/ Receiver Adapter

Model:BC108



Please read the manual



Contents

- [1 Introduction](#)
- [2 Receiving Shipment](#)
- [3 Contents of Package](#)
- [4 Warnings and safety instructions](#)
- [5 Instructions for OPERATION](#)
- [6 Technical Dat](#)
- [7 Maintenance and Cleaning](#)
- [8 Storage](#)
- [9 Discarding – Recycling](#)
- [10 Service and Warranty](#)
- [11 Disclaimer](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

Introduction

- This highly portable, lightweight wireless audio transmitter and receiver is an ideal wireless audio solution for a wide range of situations and applications.
- Transmitter mode: wirelessly streams audio from your non-Bluetooth TV, stereo system, or CD player to your Bluetooth headphones or speakers.
- Receiver mode: wirelessly streams audio from your Bluetooth phone, tablet, or computer to your wired stereo, speakers, or headphones.
- Switch between transmitter and receiver modes with a simple press of a button.
- Connect effortlessly via advanced Bluetooth technology and a 3.5mm audio cable (included).

Receiving Shipment

- When you receive the shipment, check that the contents of the package correspond to the packing slip. Inform your supplier if any parts are missing. If the equipment appears damaged, complain to the carrier immediately and give the supplier a detailed description of the damage. Keep the damaged packaging to substantiate your complaint.

Contents of Package

- TRANSNET Bluetooth 4.2 Audio Transmitter/Receiver Adapter – Model BC108 – EAN8719327259061
- Attached accessories
 - + 1 x Bluetooth 4.2 Audio Transmitter/Receiver Adapter
 - + 1 x Micro USB Charging Cable
 - + 1 x RCA Cable
 - + 1 x 3.5mm AUX Cable
 - + 1 x manual

Warnings and safety instructions

- Make sure that the packaging material does not fall into the hands of children. They may suffocate!





Read the instructions carefully before use and keep them in a safe place!



- Please note the risks and consequences associated with the incorrect use and installation of the product. This may result in personal injury and damage to the device or products connected to it.
- Use the product only for the purposes specified in this manual.
- If the product or its accessories malfunction are dropped or damaged, DO NOT use them and consult Customer Service.
- The product is designed and intended for private use. Do not use it for commercial purposes.
- DO NOT pull on the cord to unplug the appliance. DO NOT move the appliance by pulling or twisting the cord. DO NOT trip over the cable or make sure that the cable is NOT kinked, twisted, or trapped.
- The product should not be assembled by children or by people with physical or mental disabilities. The device may only be used if a supervisor is present who is responsible for the user's safety.
- Use and store the product out of the reach of children.

- DO NOT disassemble, repair, or restore the product and its parts. This may cause damage to the unit and accessories. For your own safety, these parts should only be replaced by authorized service personnel. Always send the product to a service center for repair in order to avoid damage and personal injury.
- Before connecting the product, make sure that the mains voltage indicated on the type plate matches that of your mains.
- DO NOT use or install the product near a bathtub, shower, swimming or, or near a sink or basin filled with water. DO NOT allow the product and accessories to come into contact with water. DO NOT immerse them in water.
- If water gets into or on the product or accessories, switch off the device immediately and contact our customer service. DO NOT touch the product or accessories with wet hands.
- Carefully inspect the place where you place the product and DO NOT place it In places with high temperature/humidity or where the product may come into contact with water; Near ventilation grills or places with a lot of dust or fumes; On vertical or sloping surfaces; In places where shocks or vibrations are frequent.
- Do not drop the product and accessories and protect the product from strong impacts.

Instructions for OPERATION

RX RECEIVER MODE	 <p>1-1. Switch to RX mode 1-2. Plugin the earphone by which you want to receive the Bluetooth signal. 1-3. LONG PRESS the power switch button to turn on the Bluetooth signal.</p>	 <p>1-4. When the BLUE indicator light is flashing, you can search and connect it on your device with the name "KN319".</p>
------------------	--	--

TX TRANSMITTER MODE	 <p>2-1. Switch to TX mode 2-2. Plug in the cable of the device that you want to transmit the Bluetooth signal. 2-3. LONG PRESS the power switch button to turn on the Bluetooth signal</p>	 <p>2-4. When the RED indicator light is flashing, it will connect with other Bluetooth devices automatically</p>
AFTER USE	 <p>3-1. LONG PRESS the power switch button until the indicator light is off. 3-2. Use the included micro USB-USB cable to charge the product.</p>	

Technical Dat

Colour	black
Weight	61 g
Carkit	No
Packaging width	79 mm
Packaging height	25 mm
Packaging length	134 mm

Maintenance and Cleaning

- Clean the product with a clean, dry cloth. Do NOT allow the product and other accessories to come into contact with water.

Storage

- Store the product and accessories in a dry, clean place. Do not store the device in extremely high or low

temperatures.

Discarding – Recycling

- Think of the environment and contribute to a cleaner living environment! At the end of its life, do not throw away the product and its accessories with normal household waste, but take them to a governmental collection point for recycling.

Service and Warranty

- If you need service or information about your product, please do not hesitate to send an e-mail to customerservice@best2buy.nl
- We grant a 1-year warranty on our products. The customer must be able to present proof of purchase and the guarantee must be claimed within a period of 1 year from the date of purchase. Please note that the guarantee does not apply: for damage caused by incorrect use or repair; for parts subject to wear and tear; for defects of which the customer was aware at the time of purchase; for defects caused by the customer's own fault; for damage caused by third parties.

Disclaimer

- Changes subject to change; specifications may change without notice



IS CONNECTING TO YOU

Rijswijk, Netherlands

Documents / Resources

A small image of the TRANSNECT BC108 Audio Transmitter/Receiver Adapter. It is a blue rectangular device with the TRANSNECT logo and product details printed on it.	TREANSNECT Audio Transmitter/ Receiver Adapter BC108 [pdf] User Manual TREANSNECT, Audio Transmitter, Receiver Adapter, BC108
---	--