

TRENTECH ROCKETMAN Bluetooth Speaker and Galaxy Projector User Manual

Home » TRENTECH » TRENTECH ROCKETMAN Bluetooth Speaker and Galaxy Projector User Manual



Contents

- 1 TRENTECH ROCKETMAN Bluetooth Speaker and Galaxy
- **2 ROCKETMAN BUTTON OPERATIONS:**
- **3 REMOTE OPERATIONS:**
- **4 REMOTE OPERATIONS:**
- 5 SPECS:
- **6 SAFETY RULES:**
- 7 WARRANTY:
- **8 FCC STATEMENT:**
- 9 FCC STATEMENT CONTINUED:
- **10 RF WARNING STATEMENT:**
- 11 TO EXPLORE:
- 12 Product Specifications:
- 13 FAQ:
 - 13.1 Q: What will void the warranty of the Rocketman?
- 14 Documents / Resources
 - 14.1 References
- **15 Related Posts**



USER MANUAL

ROCKETMAN BUTTON OPERATIONS:

WARNING:

BRIGHT LIGHT - DO NOT LOOK DIRECTLY INTO THE LIGHT

NOTE:

UNIT MUST BE PLUGGED IN TO WORK

ROCKETMAN BUTTON OPERATIONS:



1. POWER BUTTON – Long press to turn on/off.

A. Turn speskeorn – Long Press

Boot Status: Defaults to Bluetooth mode – Speaker will make jingle noise. Open settings on your device – make sure Bluetooth is turned on. Open the Bluetooth menu, connect to device listed as "ROCKETMAN?Th.e speaker wil make jingle noise to confirm connection. If the Bluctooth device was previously connected, it will automatically reconnect.

B. Short press: Play/Pause

C. Long Press: Turn off

D. Speaker defaults to 0% Volume when turned on

E. Volume will sync with phone

2. BT/WN BUTTON

A. Short Press: Switch between Bluetooth & White Noise

B. Long Press: Disconnects from Bluetooth. Short press will reconnect.

3. BUTTON

A. Long Press – reduce volume (will say Volume Minimized when at lowest point)

B. Short Press - Previous Song



A. Long Press – increase volume (will say Volume Maximized when at the loudest point)

B. Short Press - Next song


5. TYPE-C POWER INPUT

6. ROCKET LIGHT BUTTON - BUTTON IS ON THE ROCKET

A. Long Press: turns the light on/off

B. Short Press: changes Rocket color – 9 color options.

REMOTE OPERATIONS:



REMOTE OPERATIONS:

- 1. POWER BUTTON: Short press to turn the lights on or off. When turned on will default to Bluetooth mode.
- 2. STAR BUTTON: Short press turns stars on or off
- 3. BT-WN: Short press to switch between Bluetooth and White Noise
- **4. R-G-B-W:** Use these buttontso change Nebula colors. Short press turns the color on or off. Short press of second color creates 2 color Nebula. Can be used with single color or two color option.
- 5. +: Press & hold to make louder will say volume maximized at loudest level
- 6. -: Press & hold to make lower will say volume minimized at lowest level
- 7. >|: Short prestso advance to next song or white naise option

- 8. |<: Short press to go back to previous song or prior white noise option
- 9. >||: Short prestso play or pause
- 10. LED: Short press turns Nebula on or off
- 11. Rhythm button: Turn on / turn off Rhythm mode
- 12. * Button: Short press makes LED brighter or less bright
- 13.Fade Button 1: Short press changes the nebula to single or dual color mode
- 14. Rocket Button: Long press turns the rocket light on or off. Short press changes the color of the rocket light
- 15. Fade Button 2: Short press changes the speed of nebula ight
- 16. 1H: Thour timer light flashes once
- 17. 2H: 2 hour time light flashes twice
- **18. Timer off Button:** light flashes 3 times

SPECS:

- Bluctooth version: JL V5.3
- Bluctooth distance: 10M
- Speaker size and specification: 36mm4Q) 3W
- Material: ABS+PP
- Power supply: 100CM type C charging cable
- · Product estimated weight: 394g
- Product estimated size: 22.4 x 16 x 14.5 cm
- FCCID: 2A4HD-WE-ROCKETMAN

SAFETY RULES:

- 1. WARNING: Bright Light. Avoid Exposure. Do not stare into light.
- 2. Do not modify, repair or dismantle the product. Doing so may result in complete breakdown of the product. All of which is not covered under warranty.

Go to Trendtechbrands.com to register your product.

Must have Proof of Purchase.

Product must not show signs of physical damage or water damage for warranty coverage.

WARRANTY:

The Rocketman comes with a one year limited warranty.

The Following Situstiownisll vid the Warranty:

"Improper use of the product in accordance of the instruction manual

- * Physical Damage
- * Water Damage

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the followitnwgo conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuantto Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installatiTohni.s equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there s no guarantee that interference will not occur in a particular installation.

FCC STATEMENT CONTINUED:

IF this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the useris encouraged to trtyo correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation betweethne equipment and receiver.
- Connect the equipment into an outlet on a circuit different from thatto which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF WARNING STATEMENT:

• The device has been evaluated to meet general RF exposure requiremenTth.e device can be used in portable exposure condition without restriction.

TO EXPLORE:

Our full selection of productvissi,t us at: www.T rendzechbrands.com

Followus:





www.trendtechbrands.com

Distributed by:

Wireless Express Inc 53-57 North Mall Phinview, NY 11803 United States of America Made in China

Product Specifications:

Bluetooth version: JL V5.3Bluetooth distance: 10M

• Speaker size and specification: 36mm4 3W

· Material: ABS+PP

• Power supply: 100CM type C charging cable

• Product estimated weight: 394g

• Product estimated size: 22.4 x 16 x 14.5 cm

• FCC ID: 2A4HD-WE-ROCKETMAN

FAQ:

Q: What will void the warranty of the Rocketman?

A: The following situations will void the warranty:

- Improper use of the product in accordance with the instruction manual
- · Physical Damage
- · Water Damage

Documents / Resources



TRENTECH ROCKETMAN Bluetooth Speaker and Galaxy Projector [pdf] User Manual WE-ROCKETMAN, 2A4HD-WE-ROCKETMAN, ROCKETMAN Bluetooth Speaker and Galaxy Projector, ROCKETMAN, Bluetooth Speaker and Galaxy Projector, Speaker and Galaxy Projector, and Galaxy Projector, Galaxy Projector

References

- O Trend Tech Brands | Wireless Accessory & Electronics Retailer
- © Trend Tech Brands | Wireless Accessory & Electronics Retailer
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.