

TRIDONIC luxCONTROL BasicDIM ILD G2 Programmer Instruction Manual

Home » TRIDONIC » TRIDONIC luxCONTROL BasicDIM ILD G2 Programmer Instruction Manual

TRIDONIC lux CONTROL Basic DIM ILD G2 Programmer Instruction Manual



Contents

- 1 Operating the basic DIM ILD Programmer
 - 1.1 Basic functions
 - 1.2 Push to make switch functions
 - 1.3 Constant light control settings
 - 1.4 Offset settings
 - 1.5 Bright Out settings
 - 1.6 Presence detection profile settings
- 2 Operating basic DIM ILD with other sensors
 - 2.1 Basic functions
 - 2.2 Push to make switch functions
 - 2.3 Constant light control settings
 - 2.4 Offset settings
 - 2.5 Bright Out settings
 - 2.6 Presence detection profile settings
 - 2.7 Interface operating mode settings
 - 2.8 Return of power settings
- 3 Documents / Resources
- **4 Related Posts**

Operating the basic DIM ILD Programmer





Some functions of the basic DIM ILD Programmer can also be used with Tridonic sensors. A summary table can be found at other the end of this document under "Operating basic DIM ILD with other sensors

basic DIM ILD Programmer can be used to set parameters for the basic DIM ILD module. The following parameters are available:

Basic functions

| Icon | Designation | Description |
|-----------|-------------------------|---|
| ON | ON | Switch luminaires on |
| OFF | OFF | Increase current dimming leve |
| | Dim up | Decrease current dimming level |
| | Dim down | Change to automatic mode Dimmin g is started |
| AUTO AUTO | Automatic mode | Store the brightness level currently measured by the sensor as target v alue for constant light |
| SET | Set current light level | Store the brightness level currently measured by the sensor as target v alue for constant light control |

Push to make switch functions

The abbreviation PTM stands for "push to make switch".

| Icon | Designation | Description |
|--------|-------------|---|
| SET ON | PTM Set ON | PTM Set ON Enable storage of targ et level via push to make switch inp ut double clicking the push to make switch at the push to make switch i nput allows storing the brightness I evel currently measured by the sen sor as target level for constant light control |
| OFF | PTM Set OFF | Disable storage of target level via p ush to make switch input storing th e target level via push to make swit ch input is not possible |

Constant light control settings

NOTICE

The light levels indicated are based on a standard room situation and may differ from the levels actually measured in the task area.

• Try all three light levels and select the one most suitable!

| Icon | Designation | Description |
|-------|--------------------|---|
| K ■ | Light level | low Set ambient light control to a le vel of approx. 150 lx |
| CUX E | Light level middle | Set ambient light control to a level of approx. 300 lx |
| LUX = | Light level high | Set ambient light control to a level of approx. 500 lx |

Offset settings

Use the Offset settings to specify and define in detail differences in brightness between the two channels.

| Icon | Designation | Description |
|-------|------------------------|--|
| OFF | Offset Value 0 % | Set the difference in brightness bet ween channel 2 and channel 1 to 0 % |
| -30% | Offset Value -30 % | Set the difference in brightness bet ween channel 2 and channel 1 to -3 0 % |
| -50% | Offset Value -50 % | Set the difference in brightness bet ween channel 2 and channel 1 to -5 0 % |
| ON ON | Offset Mode Converging | Reduce the difference in brightness between channel 2 and channel 1 a t increased or reduced dimming lev el. For example: at an offset value of -30 %, one channel's dimming le vel is 30 % lower than the other's (e .g |

| OFF | Offset Mode Fixed | Maintain the difference in brightnes s between channel 2 and channel 1 at increased or reduced For exampl e: at an offset value of -30 %, one c hannel's dimming level is 30 % low er than the other's (e.g. channel 2: 40 %; channel 1: 70 %). When dim med up, channel 2 will remain at a I evel of 70 % as soon as channel 1 has reached the dimming level of 1 00 %. |
|-----|-------------------|--|
|-----|-------------------|--|

Bright Out settings

The Bright Out function defines how the ambient light control system will respond to additional illumination by sunlight or other light

| Icon | Designation | Description |
|------|---------------|---|
| ON | Bright Out ON | Switch on Bright Out: if the measur ed light level exceeds 150 % of the target level for more than 10 minute s, the light is switched off. If the me asured light level falls below 100% of the target level, the PHASED light is switched back on again. |

basicDIM ILD Programmer: Functions and Parameters | 12-2018 | en

| OFF | Bright Out OFF | Switch off Bright Out: The light rem ains switched on at all times, irresp ective of the light level measured. |
|-----|----------------|--|
|-----|----------------|--|

Presence detection profile settings

The abbreviation P.I.R. stands for "passive infrared". This function is used to control presence detection.

| Icon | Designation | Description |
|------|-------------|-------------|
| | | |

| OFF | P.I.R. inactive | Disable presence detection Run-on time is automatically set to "infinite" |
|-------------|------------------|--|
| only OFF | P.I.R. off only | Presence detection responds only to absence light must be switched on manually (push to make switch, remote control) if no persons are detected, light is switched off automatically Run-on time is au |
| ON OFF | P.I.R. active | Enable presence detection light is s witched on and off automatically ba sed on the presence/absence of a p erson Run |
| 1 min | Time delay 1min | 1 minute after the last presence wa s detected, light is dimmed to Sec. Level |
| 10 min | Time delay 10min | n-on time to 10 minutes 10 minutes after the last presence was detecte d, light is dimmed to Sec. Level |
| 20 min | Time delay 20min | 20 minutes after the last presence was detected, light is dimmed to Se c. Level |

| 0 min | If vacant 0min. | Set switch-off delay to 0 minutes lig ht is switched off immediately after r un-on time has expired |
|--------|----------------------|--|
| 1 min | If vacant 1min. | Set switch-off delay to 1 minute ligh t is switched off 1 minute after run-o n time has expired |
| 30 min | If vacant 30min. | Set switch-off delay to 30 minute lig ht is switched off 30 minutes after r un-on tim has |
| | If vacant continuous | Set switch-off delay to "infinite" (neverOFF) light is not switched off after |
| 1% | Sec. Level 1% | Set the absence level to 1 % = dim ming level to which the light is dim med after the run-on time has expir ed |

| 10% | Sec. Level 10% | Set the absence level to 10 % = di mming level to which the light is di mmed after the run-on time has exp ired; applies only if "if vacant" 0min |
|-----|----------------|--|
| 30% | Sec. Level 30% | Set the absence level to 30 % = di mming level to which the light is di mmed after the run-on time has exp ired; applies only if "if vacant" 0min |
| 50% | Sec. Level 50% | Set the absence level to 50 % = di mming level to which the light is di mmed after the run-on time has exp ired; applies only if "if vacant" 0min |

basicDIM ILD Programmer: Functions and Parameters | 12-2018 | en

| Icon | Designation | Description |
|------|-------------|---|
| DALI | DALI | Select DALI Broadcast as interface operating mode |
| DSI | DSI | Select DSI as interface operating m ode |

| Icon | Designation | Description |
|-------|-------------|--|
| ON ON | Power Up ON | luminaire is switched on again after a mains break |
| OFF | Power off | luminaire is switched on again after a mains break |

Operating basic DIM ILD with other sensors

Basic functions

| Icon | Designation | DALI MSensor 0 2 / MSensor 5D PI 14 | basicDIM DGC | SMART Sensor 5-10DPI 19f | DSI PTM |
|--------------|--------------------------|---|--------------|-----------------------------|-------------------------|
| ON | ON | ~ | ~ | ~ | > |
| OFF | OFF | V | <u> </u> | V | V |
| | Dim up | V | > | V | > |
| lacktriangle | Dim down | ~ | ~ | ~ | $\overline{\mathbf{v}}$ |
| AUTO AUTO | Automatic mode | ~ | ~ | ~ | > |
| SET SET | Set current light le vel | ~ | ~ | ~ | ~ |

Push to make switch functions

The abbreviation PTM stands for "push to make switch"

| Icon | Designation | DALI MSensor 02 / MSensor 5 DPI 14 | basicDIM DGC | SMART Sensor 5-10DPI 19fe | DSI PTM |
|------|-------------|--|--------------|------------------------------|----------|
| SET | PTM Set ON | | ~ | | ~ |
| OFF | PTM Set OFF | | ~ | | ~ |

| Icon | Designation | DALI MSensor 0 2 / | basicDIM DGC | SMART Sensor 5-10DPl 19fe | DSI-SMART PT M |
|--------|------------------------|-----------------------|--------------|------------------------------|-------------------|
| rinx 🛅 | Light level low | | ~ | | ▽ |
| K LUX | Light level middl e | | V | | ~ |
| LUX | Light High | | V | | ~ |

Offset settings

| Icon | Designation | DALI MSensor 02 / MSensor 5 DPI 14 | basicDIM DGC | SMART Sensor 5-10DPI 19fe | DSI-SMART PT M |
|--|----------------------------|--|--------------|------------------------------|-------------------|
| -Ç-Ç- OFF | Offset Value 0 % | | ~ | | |
| -\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\ | Offset Value -30 % | | ~ | | |
| -50% | Offset Value -50 % | | | | |
| ON ON | Offset Mode Conv erging | | | | |
| OFF | Offset Mode Fixed | | | | |

Bright Out settings

| Icon | Designation | DALI MSensor 0 2 / MSensor 5D PI 14 | basicDIM DGC | SMART Sensor 5-10DP I 19fe | РТМ |
|------|----------------|---|--------------|----------------------------------|-----|
| ON | Bright Out ON | | ~ | | |
| OFF | Bright Out OFF | | ~ | | |

Presence detection profile settings

| Icon | Designation | DALI MSensor 0 2 / MSensor 5D PI 14 | basicDIM DGC | SMART Sensor 5-10DPI 19fe | PTM |
|-------------|-----------------------|---|--------------|------------------------------|--|
| OFF | P.I.R. inactive | | <u> </u> | | ~ |
| only OFF | P.I.R. off only | | ~ | | ~ |
| ON OFF | P.I.R. active | | ~ | | ~ |
| 1min | Time delay 1min. | | ~ | | ~ |
| 10 min | Time delay 10min | | ~ | | ~ |
| 20 min | 20min | | ~ | | V |
| 0 min | If vacant 0min | | ~ | | ~ |
| | 1 | | | <u> </u> | |
| 1 min | If vacant 1min. | | ~ | | ~ |
| 30 min | If vacant 30min. | | ~ | | ~ |
| ™ | If vacant continu ous | | ~ | | ~ |
| 1% | Sec. Level 1% | | > | | |
| 10 % | Sec. Level 10% | | | | |
| 30% | Sec. Level 30% | | ~ | | ~ |
| 50% | Sec. Level 50% | | ~ | | ~ |

Interface operating mode settings

| Icon | Designation | DALI MSensor 0 2 / MSensor 5D PI 14 | basicDIM DGC | SMART Sensor 5-10DPI 19fe | PTM |
|------|-------------|---|--------------|------------------------------|-------------|
| DALI | DALI | | ~ | | V |
| DSI | DSI | | ~ | | > |

Return of power settings

| Icon | Designation | DALI MSensor 0 2 / MSensor | basicDIM | SMART Sensor 5-10DPI 19fe | DSI-SMART PT M |
|-------|--------------|-------------------------------|----------|------------------------------|-------------------|
| ON ON | Power Up ON | | V | | ✓ |
| OFF | Power Up OFF | | ~ | | ~ |

TRIDONIC

Documents / Resources



TRIDONIC IuxCONTROL BasicDIM ILD G2 Programmer [pdf] Instruction Manual IuxCONTROL BasicDIM ILD G2 Programmer, IuxCONTROL, BasicDIM ILD G2 Programmer, ILD G2 Programmer, G2 Programmer, Programmer

Manuals+,