



TROTEC T660 Capacitive Humidity Meter User Guide

[Home](#) » [TROTEC](#) » TROTEC T660 Capacitive Humidity Meter User Guide 

Contents

- [1 TROTEC T660 Capacitive Humidity Meter](#)
- [2 HOW CAN USE](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)



TROTEC T660 Capacitive Humidity Meter



HOW CAN USE

1. Turn on the unit on the power button on the right hand side hold the unit in the air while hand is down the bottom of the unit far away from the steel ball.
2. Touch the keypad to light up the screen
3. Hold the menu button down till the menu appears this left arrow button (west)
4. Press the down arrow (south) till the MAT is flashing on the screen
5. Press the tick button
6. The number "0" will be flashing
7. Press the up arrow (north) twice the 2 CE will appear
8. Hold the Tick button
9. It will now show 2 values:
 - 0.0
 - 0.0
10. The Top number 0.0 will go to 7.6 that's volume mass for con-crete and should read under 3.4 if you press the up arrow (north) the CM will appear this is a Calcium Carbide Equivalent

11. This is going down 40 mm and should read under 2.0 which is an equivalent to 75% relative humidity

12. The Bottom number goes to 200 digits this is a relative scale for all other building materials

13. Using the left hand arrow (west) you can scroll between:

Actual reading,


Minimum reading,

Maximum reading,

Average reading

and hold to take screen readings (on the hold button to change to take a new screen readings press the tick button)

Documents / Resources



[TROTEC T660 Capacitive Humidity Meter](#) [pdf] User Guide
T660, Capacitive Humidity Meter