



TROTRONICS TT-DL060 LED Floor Lamp User Guide

[Home](#) » [TROTRONICS](#) » TROTRONICS TT-DL060 LED Floor Lamp User Guide 

Contents

- [1 TROTRONICS TT-DL060 LED Floor Lamp](#)
- [2 Product Diagram](#)
- [3 Assembly and Disassembly](#)
- [4 How to Use](#)
- [5 Specifications](#)
- [6 FCC Compliance](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)




TROTRONICS TT-DL060 LED Floor Lamp





Product Diagram

1. Lamp Head
2. Gooseneck
3. Control Panel
4. Power Socket
5. Pole Section #3
6. Pole Section #2
7. Pole Section #1
8. Base



Assembly and Disassembly






Note:

- When connecting the sections, rotate in opposite directions with both hands and do not screw with too much force.
- You can choose to use different numbers of sections for different purposes and scenes. To disassemble, follow the assembly steps as above in the reverse order.

How to Use



1. Brightness Indicator
2. Color Temperature Button
3. Brightness +
4. Brightness –
5. Power Indicator
6. Power Button

Standby Mode

Connect the lamp to a power source and it will enter standby mode. The Power Indicator on the Power Button will light up in blue.

Power On / Off

Tap the Power Button to turn the lamp on / off.

Color Temperature / Brightness Adjustment

Tap the Color Temperature Button to cycle through 5 color temperature settings. Tap the Brightness + / – Button to adjust the brightness.

Adjust the Lamp Head

Note: Please do not turn the lamp head for over 180° to avoid damaging the gooseneck.

Thank you for choosing the TaoTronics TT-DL060 LED Floor Lamp. If you have any questions or concerns, please contact our customer support team by email at support@taotronics.com.

Specifications

Model	TT-DL060
Light Source	LED
Operate Voltage	DC 12V 1.5A
LED Power	12W
Color Temperature	3000K – 6500K
Lumens	780 lm max
Ra	> 80

Caution

- Please do not dismantle the product by yourself, always ask a professional electrician or authorized technician for repairs.

- If you smell a bad odor or anything unusual, please turn off the unit immediately.
- Please do not remove the power cable with wet hands as it may cause an electric shock.
- Do not put this unit near extreme heat sources, moisture, or corrosive substances.
- Clean the lamp with a dry cloth when needed.
- Please store the lamp in a dry and shady place if not being used for a long period of time.
- Use the original power adapter to power the lamp. A wrong input may damage the lamp.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must withstand any interference received, including interference that may cause undesired operation. [support.uk@taotronics.com\(UK\)](mailto:support.uk@taotronics.com)

Documents / Resources

	TROTRONICS TT-DL060 LED Floor Lamp [pdf] User Guide TT-DL060, LED Floor Lamp
---	---

[Manuals+.](#)